RCA

Television User's Guide

Changing Entertainment. Again.

GUIDEplus+™ GOLD
GEMSTAR

Downloaded from www.Manualslib.com manuals search engine

Important Information

WARNING

To reduce the risk of fire or electric shock, do not expose this TV to rain or moisture.

WARNING
RISK OF ELECTRIC SHOCK
DO NOT OPEN

To reduce the risk of electric shock, do not remove cover (or back). No user serviceable parts inside. Refer servicing to qualified service personnel.

This symbol indicates "dangerous voltage" inside the product that presents a risk of electric shock or personal injury.

This symbol indicates important instructions accompanying the product.



Caution: To prevent electric shock, match wide blade of plug to wide slot, fully insert.

Attention: Pour éviter les chocs électriques, introduire la lame la plus large de la fiche dans la borne correspondante de la prise et pousser jusqú au fond.

Refer to the identification/rating label located on the back panel of your product for its proper operating voltage.

FCC Regulations state that unauthorized changes or modifications to this equipment may void the user's authority to operate it.

If fixed (non-moving) images are left on the screen for long periods, they may be permanently imprinted on the picture tube. Such images include network logos, phone numbers, and video games. This damage is not covered by your warranty. Extended viewing of channels displaying these images should be avoided.

Cable TV Installer: This reminder is provided to call your attention to Article 820-40 of the National Electrical Code (Section 54 of the Canadian Electrical Code, Part 1) which provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building as close to the point of cable entry as practical.

Product Registration

Please fill out the product registration card and return it immediately. Returning the card allows us to contact you if needed.

Keep your sales receipt to obtain warranty parts and service and for proof of purchase. Attach it here and record the serial and model numbers in case you need them. The numbers are located on the back of the television.

Model No._____

Serial No. _____

Purchase Date:_____

Dealer/Address/Phone: _____

G-LINK, VCR Plus+, C³, PlusCode, GUIDE Plus+, and GUIDE Plus+ Gold are trademarks of Gemstar Development Corporation.

The GUIDE Plus+ Gold system is manufactured under license from Index Systems Inc.

Thomson Consumer Electronics and Gemstar are not in any way liable for the accuracy of the program information provided by the GUIDE Plus+ System. In no event shall Thomson Consumer Electronics or Gemstar be liable for any amount representing loss of profits, loss of business, or indirect, special, or consequential damages in connection with the provision or use of any information equipment, or services relating to the GUIDE Plus+ System.

Downloaded from www.Manualslib.com manuals search engine

Key Features Overview

Your TV is equipped with features that will add to your TV viewing experience. The following information summarizes a few of these features. Chapter 3 provides more information about the rest of the TV's features and how to use them.

10:06pm
1 Watch 2 Go To 3 Record
Late Night with Conan O'Brien: actor Stephen Baldwin; author Mark Leyner; comedian Robert Schimmel; the Brian Setzer Orchestra
NBC [7] 10:00pm (1 hr) cc
Grid Sort News Schedule
Wed 10:00pm 10:30pm
Last Channel The Nanny Everybody L...
Spin City Dharma & Gr...
Beverly Hills 90210
CBS The Nanny Everybody L...
Late Night wi... Working
Gone With the Wind
Good Morning, Vietnam
PBS Mark Russell Great Perfor...
Big Show
Dateline
Air Force One retires
Mon. at 10:00
Fitness Tip
Steppin' Out Free & Easy
more

On-screen Program Guide

Description: The GUIDE Plus+ system is an on-screen interactive list of programs and information that is built into your TV. You can scroll through the guide to see what's on and tune directly to that program from the guide. You can also browse programs by category with the sort feature.

When you access the *News* feature, MSNBC will appear in your video window if it's available through your TV.

One-Touch VCR Recording is another benefit of the GUIDE Plus+ system. You don't have to remember to program your VCR or use the menus in your VCR to set up a recording.

Requirements:

- Remove the Demo Pin from the G-LINK jack.
- Complete the on-screen interactive setup. You'll find detailed instructions in Chapter 1.
- One-Touch VCR Recording: You must connect the G-LINK cable to the TV and place one of the wands in front of the remote sensor on the VCR.
- If you have a cable box, connect the G-LINK cable to the TV and place one of the wands in front of the remote sensor on the cable box.



PIP (Picture-In-Picture)

Description: PIP lets you watch two channels at one time — one channel on the main screen and the other in a smaller window.

Requirements: Connect audio/video cables to your TV and to another component that has a tuner (a VCR or a satellite receiver).

Your TV has one tuner, which means it can tune to one channel at a time. You must set up a second component (VCR or satellite receiver) to act as the second tuner in order for PIP to work. Chapter 1 and Chapter 5 have detailed instructions.

Downloaded from www.Manualslib.com manuals search engine


V-CHIP TV RATING LIMIT
- - Content - -
Rating Status D L S V FV
TV-14 View V V V V
Press ^/v to view programs with
this content for this rating.
RATING STATUS D L S V FV
TV-MA View B V V
TV-14 View V V V V
TV-PG View V B V V
TV-G View
TV-Y7 View V
TV-Y View

V-Chip: Parental Controls

Description: You can block programs and movies by content, age-based ratings, and/or movie ratings.

Requirements:

- Set up the *Parental Controls* menu in the TV's main menu (Chapter 3 has details).
- The broadcasters must use the rating system when they send the program to your TV in order for your TV to block the program.

Auto Tuning

Description: Allows you to set up the TV to automatically tune to a specific channel when you press a certain component (VCR, DVD Player, etc.) button on the remote.

Requirements: Set up *Auto Tuning* in the TV's menu system. (Chapter 3 has details).

Downloaded from www.Manualslib.com manuals search engine

Table of Contents

Introduction

Key Features Overview **1**
- On-screen Program Guide 1
- PIP (Picture-In-Picture) 1
- V-Chip: Parental Controls 2
- Auto Tuning 2

Chapter 1: Connections & Setup

Things to Consider Before You Connect **6**
- Protect Against Power Surges 6
- Protect Components from Overheating 6
- Position Cables Properly to Avoid Audio Interference 6
- Important Stand and Base Safety Information 6
- Use Indirect Light 6
- Connection Pictures 6
- Demo Pin 6

Choose Your Connection **7**
Connection: TV + VCR **8**
Connection: TV Only (No PIP) **9**
Connection: TV + VCR + Satellite Receiver **11**
Connection: TV + VCR + Cable Box **12**
Why You Should Connect This G-LINK Cable **13**
- How to Find the Remote Sensor 13
- Placing the G-LINK Wands 13

Complete the Interactive Setup **15**
- Set the Menu Language 15
- Complete Auto Channel Search 15
- The GUIDE Plus+ System Setup 15

What to Expect **20**
Next Steps **20**

Chapter 2: Using the Remote Control

The Buttons on the Remote Control **22**
- Using the WHO•INPUT Button 23

Programming the Remote to Operate Other Components **24**
- Find Out If You Need to Program the Remote 24
- How to Program the Remote 24

How to Use the Remote After You've Programmed It **25**

Chapter 3: Using the TV's Features

About the GUIDE Plus+ System **28**
- Downloading Data 28
- Getting In & Out of the GUIDE Plus+ System 29
- The GUIDE Plus+ System Menus 29
- Grid Guide 29
- Sort 31
- News 32

Downloaded from www.Manualslib.com manuals search engine

Table of Contents

Schedule 32
Messages 33
Channels 34
Setup 34
How to Get More Information About an Advertisement or a Program 35
GUIDE Plus+ Menu Items 35
Channel Banner 36
The PIP (Picture-In-Picture) Feature 36
PIP Troubleshooting 38
Why You Should Use the Auto Tuning Feature 38
How to Set Up the Auto Tuning Feature 38
Parental Controls and V-Chip 40
How V-Chip Works 40
V-Chip TV Rating Limit 41
Blocking Specific Content Themes 43
Viewing Specific Content Themes 44
V-Chip Movie Rating Limit 44
V-Chip Unrated Program Block 45
Channel Block 46
Front Panel Block 46
Lock/Unlock Parental Controls 46

Chapter 4: Using the TV's Menu System

How to Use Your TV's Menu System 48
Audio Menu 49
Picture Quality Menu 50
Screen Menu 50
Using Closed Captioning 51
Channel Menu 52
Time Menu 52

Chapter 5: Other Information

Troubleshooting 54
Care and Cleaning 57
Front Panel 57
RCA TV Limited Warranty 58
Index 61

Downloaded from www.Manualslib.com manuals search engine

Connections & Setup

Chapter Overview:

- Things to Consider Before You Connect
- Choose Your Connection
- Connections
- Why You Should Connect This G-LINK Cable
- Plug in the TV
- Put Batteries in the Remote
- How to Use the Remote Control to Complete the Interactive Setup
- Turn on the TV
- Complete the Interactive Setup

Changing Entertainment. Again.

Downloaded from www.Manualslib.com manuals search engine

Things to Consider Before You Connect

Protect Against Power Surges

- Connect all components before you plug any of their power cords into the wall outlet.
- Turn off the TV and/or component before you connect or disconnect any cables.
- Make sure all antennas and cables are properly grounded. Refer to the Important Safeguards sheet packed with your TV.

Protect Components from Overheating

- Don't block ventilation holes on any of the components. Arrange the components so that air can circulate freely.
- Don't stack components.
- When you place components in a stand, make sure you allow adequate ventilation.
- If you connect an audio receiver or amplifier, place it on the top shelf so the heated air from it won't flow around other components.

Position Cables Properly to Avoid Audio Interference

- Insert each cable firmly into the designated jack.
- If you place components above the TV, route all cables down the side of the back of the TV instead of straight down the middle of the back of the TV.
- If your antenna uses 300-ohm twin lead cables, do not coil the cables. Also, keep the twin lead cables away from audio/video cables.

Important Stand and Base Safety Information

Choose the location for your TV carefully. Place the TV on a stand or base that is of adequate size and strength to prevent the TV from being accidentally tipped over, pushed off, or pulled off. This could cause personal injury and/or damage the TV. Refer to the Important Safeguards sheet packed with your TV.

Use Indirect Light

Don't place the TV where sunlight or room lighting will be directed toward the screen. Use soft or indirect lighting.

Connection Pictures

Audio/video cables are usually bundled together. For better visibility, the connection pictures in this book show each cable separately (audio left, audio right, and video).


DEMO PIN
This Demo Pin activates an automatic GUIDE Plus+ demo.
RETAILERS:
Do NOT remove this Demo Pin. Removal will disable the automatic demo.
CONSUMERS:
REMOVE this Demo Pin and insert the G-Link cable here before using this TV.

Demo Pin

You must remove the Demo Pin from the G-LINK jack on the back of your TV in order for your TV to operate properly and to connect the G-LINK cable.

Downloaded from www.Manualslib.com manuals search engine

Choose Your Connection

There are several ways to connect your TV. Please use the following chart to determine which connection is best for you. Proceed to the appropriate page and connect your TV.

Components	Cables Needed	Connection Title	Go to...
TV VCR	Coaxial Audio/video G-LINK cable	TV + VCR	page 8
 TV	Coaxial	TV Only (No PIP)	page 9
TV VCR Satellite	Coaxial Audio/video S-Video (optional) G-LINK cable	TV + VCR + Satellite Receiver	pages 10-11
TV VCR  Cable Box	Coaxial Audio/video G-LINK cable	TV + VCR + Cable Box	page 12

Cables Needed to Connect Components to Your TV

The pictures below show the cables needed for the connections represented in this book.

Notes: *Audio/Video cables (A/V cables for short) are usually sold as a bundled set, but the connection pictures in this book show each cable separately for better visibility. You must use A/V cables to connect a VCR to your TV if you want PIP (Picture-In-Picture) to work.*

Please locate the G-LINK cable (provided) when you're getting ready to set up your TV. You need to connect this cable to your TV, and to your VCR and/or cable box in order for all of the features of the program guide to work properly.


G-LINK cable


Audio/Video cables


Coaxial cable


S-Video cable

Downloaded from www.Manualslib.com manuals search engine



You need to connect your VCR to your TV with audio/video cables in order for Picture-In-Picture (PIP) to work (see picture above).

Connection: TV + VCR

1. Connect your TV to your VCR

A. Connect a coaxial cable to the CABLE/ANTENNA jack on your TV and to the Output Jack on your VCR (sometimes labeled OUT TO TV).

B. Connect the audio/video cables. Connect audio cables (white and red) to the AUDIO IN jacks on the back of the TV (R and L/MONO) and to the Audio Output Jacks on the VCR (sometimes labeled OUT R L).

C. Connect the video cable (yellow) to the VIDEO IN jack on the back of the TV and to the Video Output Jack on the VCR.

2. Connect cable or antenna to your VCR

Connect the coaxial cable from your cable outlet, cable box, or antenna to the Input Jack on your VCR (sometimes labeled IN FROM ANTENNA or IN FROM ANT).

3. Connect the G-LINK cable to the TV

A. If you haven't already done so, remove the Demo Pin from the G-LINK jack.

B. Connect the G-LINK cable to the G-LINK jack on the TV. Next step, place one of the wands of the G-LINK cable to work with your VCR (instructions are on p. 13).

Go to page 13

Downloaded from www.Manualslib.com manuals search engine





PIP (Picture-In-Picture) won't work if you use this connection. You must connect a VCR to your TV with audio/video cables in order for PIP to work.

Connection: TV Only (No PIP)

1. **Connect the TV to your cable or antenna**

   Connect the coaxial cable from your cable or antenna to the CABLE/ANTENNA jack on the back of your TV.

Go to page 14

2. **If you're connecting a cable box, connect the G-LINK cable**

   A. If you haven't already done so, remove the Demo Pin from the G-LINK jack.

   B. Connect the G-LINK cable to the G-LINK jack on the TV. Next step, place the wands of the G-LINK cable to the cable box (instructions are on p. 13).

Go to page 13

Downloaded from www.Manualslib.com manuals search engine







You need to connect your Satellite Receiver to your TV with audio/video cables (see picture above) in order for Picture-In-Picture (PIP) to work.

Downloaded from www.Manualslib.com manuals search engine

Connection: TV + VCR + Satellite Receiver

1. Connect your Satellite Receiver to your TV

A. Connect the audio/video cables. Connect the audio cables (white and red) to the AUDIO IN jacks on the back of the TV (R and L/MONO) and to the Audio Output Jacks on the Satellite Receiver.

B. Connect the video cable (yellow) to the VIDEO IN jack on the back of the TV and to the Video Output Jack on the satellite receiver.

C. Connect S-Video cable (optional). Connect an S-Video cable to the S-VIDEO jack on the TV and to the S-VIDEO jack on the satellite receiver. (An S-Video cable provides better picture quality than a regular video cable, but it is optional.)

2. Connect coaxial cables to the Satellite Receiver

A. Connect the coaxial cable from your cable outlet, cable box, or antenna to the Input Jack on your satellite receiver (sometimes labeled IN FROM ANT).

B. Connect the coaxial cable from your satellite dish antenna to the Input Jack on your satellite receiver (sometimes labeled SATELLITE IN).

3. Connect the Satellite Receiver to the VCR and to the TV

A. Connect a coaxial cable to the Output Jack (sometimes labeled OUT TO TV) on the satellite receiver and to the Input Jack on the VCR (sometimes labeled IN FROM ANT).

B. Connect a coaxial cable to the Output Jack on the VCR (sometimes labeled OUT TO TV) and to the CABLE/ANTENNA jack on the TV.

4. Connect G-LINK cable

A. If you haven't done so, remove the Demo Pin from the G-LINK jack.

B. Connect the G-LINK cable to the G-LINK jack on the TV. Next step, place one of the wands of the G-LINK cable to work with your VCR (instructions are on p. 13).

Go to page 13

Downloaded from www.Manualslib.com manuals search engine





Note: *The GUIDE Plus+ system's One-Touch VCR Recording feature is not available with this connection. If you want to use the One-Touch VCR Recording feature with your cable box, you must use the TV and VCR connection on page 8. You can do so by routing the signal from your cable box into the antenna input on your VCR. Note that PIP won't work if you use this connection. This connection may not be compatible with all cable services, especially if some or all cable channels are scrambled.*

Connection: TV + VCR + Cable Box

1. **Connect Signal Splitter to your VCR and TV**
   - A. Use a Signal Splitter (not provided) to split the signal coming into the room. You can purchase a Signal Splitter at your local electronics store or through the Accessory Order Form on page 59.
   - B. Connect a coaxial cable to Signal Splitter and to the Input Jack on the VCR (sometimes labeled ANTENNA IN).
   - C. Connect a coaxial cable to the Signal Splitter and to the CABLE IN Jack on the cable box.

2. **Connect Cable Box to TV**
   Connect a coaxial cable to the TV OUT Jack on the cable box and to the CABLE/ANTENNA jack on the TV.

3. **Connect the TV to your VCR**
   - A. Connect the audio cables (white and red) to the AUDIO IN jacks on the TV and to the Audio Output Jacks on the VCR (sometimes labeled AUDIO OUT R and L).
   - B. Connect the video cable (yellow) to the VIDEO IN jack on the TV and to Video Output Jack on the VCR (sometimes labeled VIDEO).

4. **Connect G-LINK cable**
   - A. If you haven't already done so, remove the Demo Pin from the G-LINK jack on the TV.
   - B. Connect the G-LINK cable to the G-LINK jack on the TV. Next step, place the wands of the G-LINK cable to work with the VCR and cable box (instructions are on p. 13).

Go to page 13

Downloaded from www.Manualslib.com manuals search engine

Why You Should Connect This G-LINK Cable

The G-LINK cable enables the GUIDE Plus+ system (the on-screen interactive program guide) to work with your VCR and/or cable box.

Cable Box – If your TV is connected to a cable box you must connect the G-LINK cable to receive TV program listings for your area, and to tune directly to a channel when the program guide is on your TV screen.

VCR – If your TV is connected to a VCR and you don't connect the G-LINK cable, one-touch VCR recording won't work. The other features of the guide will work properly.

How to Find the Remote Sensor



You have to place the G-LINK wands in front of the remote sensor on the VCR and/or cable box. Some cable boxes and VCRs have the remote sensor labeled on the unit. If the remote sensor isn't labeled on your VCR and/or cable box, you need to use the remote control that came with the VCR and/or cable box to locate the sensor.

1. Turn off the VCR and/or cable box.
2. Hold the remote control (**not** the one that came with your TV, but the one that came with the cable box and/or VCR to which you're attaching the G-LINK cable) so that it is touching the front of the component.
3. Slowly move the remote control across the front of the component (VCR or cable box) while you press the power button on and off. You must press and release the power button each time you move the remote (holding down the button won't work).



4. When the component turns on, you've located the remote sensor.

Placing the G-LINK Wands

Place the G-LINK wands in front of the remote sensor on your VCR and/or cable box approximately one inch away from the remote sensor (see instructions below).



Tip

If you don't have both a cable box and a VCR connected to your TV, just coil the cable of the extra G-LINK wand with a twist tie and leave it behind the TV.

Downloaded from www.Manualslib.com manuals search engine

Plug in the TV

Plug the end of the power cord into the wall outlet. Match the wide blade of the plug with the wide slot in the outlet. Insert the plug completely into the outlet.



Put Batteries in the Remote

1. Remove the battery compartment cover on the remote.
2. Insert new batteries. Match the polarities (+ and -) on the batteries with the diagram on the remote.
3. Put the battery compartment cover back on the remote.



Use the arrow buttons and the OK button to move through the menu system.

How to Use the Remote Control to Complete the Interactive Setup

The technical term is "Navigation" – how you move through the on-screen menus. The theory is the same throughout the menu screens: highlight your choice and select it.

To highlight a menu item, press the arrow buttons on the remote to highlight one of the items listed on the screen. Use the up or down arrow button to move up or down. Use the right or left arrow button to move right or left.

To select the item that you've highlighted, press OK.

> ***Note:*** *Highlighted means that the menu item stands out from other menu items on the list (appears darker, brighter, or a different color).*

Turn on the TV

Press the TV button on the remote control or the POWER button on the TV (the first screen of the Interactive Setup appears). The menu screens "time out" after a period of time if you don't make a selection. The tips in this section tell you how to access the Setup menu screens manually.

> ***Note:*** *Pressing the TV button not only turns on the TV, but puts the remote into TV mode. "TV mode" means that the buttons on the remote control operate the TV's functions.*

Downloaded from www.Manualslib.com manuals search engine

Complete the Interactive Setup

Tip

To access the setup menus manually, press MENU and choose Setup.

The menu system in your TV allows the TV's features to work properly. In this book, we call it the "interactive setup" because the TV asks you questions, you answer, and the TV makes the appropriate adjustments. The first time you turn on your TV, the setup screens appear automatically.

Set the Menu Language

The first part of the *SETUP* asks you to select your preferred language for the menu system.

1. Highlight your preferred language for the menu system.
2. Press OK to select that language.

Complete Auto Channel Search

The next part of the *SETUP* asks you if you want the TV to search for all channels viewable through your antenna or cable TV system. This is sometimes called "auto programming."

1. Press OK to tell the TV to begin searching for channels. A progress report appears on the screen.
2. When the screen on the TV tells you the search is complete, press OK (the first GUIDE Plus+ system setup screen appears).

   Note: *If you skip Auto Channel Search now, you can access it later through the Channel menu. See Chapter 3 for more details.*

The GUIDE Plus+ System Setup

Tip

If you move to a new zip or postal code, or if any of your information changes, you need to access the setup screens from the TV's main menu— press MENU, choose GUIDE Plus+ Menu, and choose GUIDE Plus+ Setup.

The GUIDE Plus+ system is an on-screen interactive program guide that lists what shows are on TV in your area. In order to receive program listings, you need to complete the following steps.

The G-LINK cable must be connected to the back of your TV, and the wands must be placed in front of the remote sensor on your cable box and/or VCR in order for the GUIDE Plus+ system to work (go back to p. 13 for details).

1. You should see a screen displaying the features of the Guide Plus+ system. Press OK to continue.
2. The next screen asks you to locate setup materials and hardware. Once you have done this, press OK to continue.

Downloaded from www.Manualslib.com manuals search engine


STEP 1: Identifying Your TV's Location
To supply your TV with correct TV program listings, the GUIDE Plus+ system needs to know your TV's location.
Which country is your TV located in?
✓USA
Canada
On your TV remote, use the up/down keys to highlight your answer. Press OK to choose.

Step 1: Identifying Your TV's Location

1. If your country is highlighted, press OK on the remote control.

   If your country isn't highlighted, press the up or down arrow button on the remote control to highlight your country and press OK.


STEP 1: Identifying Your TV's Location
Please enter the 5-digit ZIP code where your TV is located.
_____
On your TV remote, use the number keys to enter your information. Press OK to confirm.

2. Use the number buttons on your remote to enter your zip code.

   Press OK when you're finished.

   Note: *If your postal code contains letters, press the up and down arrow buttons on your remote to enter letters, and press the right arrow button to go to the next space. The left arrow button moves you to the left.*


STEP 2: Configuring for Cable
To supply your TV with correct TV program listings, the GUIDE Plus+ system needs to know if your TV receives its signal by cable or antenna.
Do you have cable service on this TV?
✓Yes
No
On your TV remote, use the up/down keys to highlight your answer. Press OK to choose.

Step 2: Configuring for Cable

The next series of screens asks you about your cable setup. To supply your TV with the correct TV program listings, the GUIDE Plus+ system needs to know if your TV is connected to cable.

1. If your TV is connected to cable, highlight *Yes* and press OK.

   If your TV isn't connected to cable, highlight *No* and press OK (*STEP 3: Configuring for a VCR* appears).


STEP 2: Configuring for Cable
You have indicated that you have cable service. Now the GUIDE Plus+ system needs some additional information.
Is a cable box connected to this TV?
✓Yes
No
On your TV remote, use the up/down keys to highlight your answer. Press OK to choose.

2. If you have a cable box connected to this TV, highlight *Yes* and press OK on your remote control.

   Note: *The next series of screens is very important because the GUIDE Plus+ system must find the correct cable box information in order to receive the correct TV program listings.*

   If you don't have a cable box connected to this TV, highlight *No* and press OK (*STEP 3: Configuring for a VCR* appears).

Tip

If you're not sure which channel is the cable box's output channel, consult the book that came with your cable box or contact your cable company.

Downloaded from www.Manualslib.com manuals search engine


STEP 2: Configuring for Cable
To operate properly with your cable box, the GUIDE Plus+ system needs to know the channel your TV is on when using the cable box. The most commonly used output channel is 03. Please consult your cable provider if you are unsure, as an incorrect selection will result in a blue or snowy screen while watching TV.
Which channel is your TV tuned to when using the cable box?
02
✓ 03
04
Video1/AUX
On your TV remote, use the up/down keys to highlight your answer. Press OK to choose.

3. Highlight the channel to which you have to tune your TV in order to see cable programming, and press OK (a screen appears reminding you to connect your G-LINK cable to your TV and cable box).

   Notes: *Channel 03 is the most common.*

   Choose Video1/AUX if your cable box is connected to your TV with audio/video cables instead of a coaxial cable. Go to page 7 for pictures of these cables.

   For more information, go to cable box connection on page 12.


STEP 2: Configuring for Cable
Selecting the correct cable box brand from the list below is needed to automatically receive TV program listings. If you do not know the cable box brand, please consult your cable provider.
What brand of cable box is connected to this TV?
Not Listed
✓ Archer
Cable Cinema
Cabletenna
On your TV remote, use the up/down keys to find your brand (more brands will appear as you move down). Press OK to choose.

4. Highlight your brand of cable box, and press OK.

   If your brand isn't listed, highlight *Not Listed* and press OK.


STEP 2: Configuring for Cable
The GUIDE Plus+ system will conduct a series of tests to find the correct code to control your cable box.
Follow steps A and B below:
A. Please tune your cable box to channel 02
B. Make sure to leave your cable box ON
Once you have completed these steps, press OK on the TV remote to begin testing.

5. Make sure your cable box is on.

   Tune the cable box to channel 02 (use the remote control that came with your cable box, or press the channel buttons on the cable box).

   Press OK (the GUIDE Plus+ system starts testing codes).

   Important Note: *When code testing is in progress, don't touch your TV, VCR, cable box or any of the remote controls for these products.*


STEP 2: Configuring for Cable
Testing complete.
If your cable box automatically changed to and remained on channel 09, the test was successful.
Is your cable box now tuned to channel 09?
✓ Yes
No
Test this code again
On your TV remote, use the up/down keys to highlight your answer. Press OK to choose.

6. Look at your cable box. If it is still on and changed to channel 09, the test was successful. Highlight *Yes,* and press OK (*STEP 3: Configuring for a VCR appears*).

   If your cable box didn't change to channel 09 or turned itself off, you have two choices: *No* and *Test this code again*.

   Test this code again: If you think the TV, the cable box, or any of the remote controls might have been touched or bumped during the test, highlight *Test this code again* and press OK (the GUIDE Plus+ system runs the same set of codes).

   No: If you don't think the test was interrupted, highlight *No* and press OK (GUIDE Plus+ system tests the next code).

   Repeat the previous instructions until the TV finds the correct cable box code. Follow the instructions on the screen.

   Note*: If the TV can't find your cable box code, a troubleshooting checklist appears. Carefully review each checklist and follow the instructions on the screen.*

Downloaded from www.Manualslib.com manuals search engine


STEP 3: Configuring for a VCR
If a VCR is connected to this TV, you can use the GUIDE Plus+ system's TV program listings to easily schedule recordings using the one-touch VCR recording feature.
Is a VCR connected to this TV?
✓Yes
No
On your TV remote, use the up/down keys to highlight your answer. Press OK to choose.

Step 3: Configuring for a VCR

1. If your TV is connected to a VCR, press OK.

   If it is not, highlight *No* and press OK (a screen will appear reminding you to connect your G-LINK cable to your TV and VCR.).


STEP 3: Configuring for a VCR
To operate properly with your VCR, the GUIDE Plus+ system needs to know the VCR brand. An incorrect brand selection may result in program recording errors.
What brand of VCR is connected to this TV?
✓Not Listed
Admiral
Adventura
On your TV remote, use the up/down keys to find your brand (more brands will appear as you move down). Press OK to choose.

2. Use the up and down arrow buttons to highlight the brand of your VCR that is connected to the TV and press OK.

   If your brand isn't listed, highlight *Not Listed* and press OK.


STEP 3: Configuring for a VCR
The GUIDE Plus+ system will now conduct a series of tests to find the correct code to control your VCR.
Follow steps A and B below:
A. Please tune your VCR to channel 02
B. Next, turn OFF your VCR
Once you have completed these steps, press OK on the TV remote to begin testing.

3. Tune your VCR to channel 02. Next, turn OFF your VCR. When you complete these steps, press OK to begin testing.

   Important Note: *When code testing is in progress, don't touch your TV, VCR, or any of the remote controls for these products.*


STEP 3: Configuring for a VCR
Testing complete.
If your VCR turned ON, changed to and remained on channel 09, the test was successful.
Is your VCR now tuned to channel 09?
✓Yes
No
Test this code again
On your TV remote, use the up/down keys to highlight your answer. Press OK to choose.

4. Look at the front display of your VCR. If your VCR turned on automatically and changed to channel 09, the test was successful. Highlight *Yes* and press OK.

   If your VCR didn't change to channel 09, you can either choose *No* or *Test this code again*.

   If you think your TV or remotes might have been touched during the test, tune your VCR to channel 02, turn off your VCR and highlight *Test this code again*.

   If you don't think the test was interrupted, highlight *No*. Tune your VCR to channel 02 and turn off your VCR. Press OK (the GUIDE Plus+ system starts testing another set of codes.)

   Keep following the previous instructions until the VCR finds the correct code.

Downloaded from www.Manualslib.com manuals search engine

Tip

Leave your cable box turned ON to download program information.

Leave your VCR turned OFF to record programs.

Note: *If the GUIDE Plus+ system can't locate the correct code for the VCR, a list of troubleshooting instructions appears to help you before you try again.*

- *Try VCR configuration again: repeat VCR setup.*
- *Test alternate codes: tests selected brands and if this fails, the test continues with all codes in the system.*
- *Skip this step: the GUIDE Plus+ system won't be able to automatically schedule programs to record on your VCR.*


STEP 4: Confirming Your Settings
You have entered the following GUIDE Plus+ system settings. If any setting is marked INCOMPLETE, you will not be able to use that feature until you complete that portion of GUIDE Plus+ system setup.
Country - USA
ZIP code - 91101
Cable - Yes
Cable box - Yes
Cable box output channel - 03
Cable box remote control code - Jerrold 01-02
VCR - Yes
VCR remote control code - RCA 01-05
Are the above settings correct?
✓ Yes, end setup
No, repeat setup process
On your TV remote, use the up/down keys to highlight your answer. Press OK to choose.

Step 4: Confirming Your Settings

1. Check to make sure all settings are complete and correct. If all settings are complete, highlight *Yes, end setup* and press OK. If your cable box and/or VCR code testing failed, you should see *INCOMPLETE* where the cable box and VCR codes are listed. Once setup is complete, additional screens appear.

   If any settings are incomplete or incorrect, highlight *No, repeat setup process* and press OK. Follow the instructions on the screen.


Congratulations!
You have completed setup of your GUIDE Plus+ system. Within 24 hours, your TV will receive your local channel lineup and TV program listings. In the meantime, you may continue normal TV viewing.
What would you like to do now?
✓Watch TV
View demo
On your TV remote, use the up/down keys to highlight your answer. Press OK to choose.

2. You can choose to view a demo of the GUIDE Plus+ features, which may take a few minutes to load. If you don't want to see the demo right now, press OK to watch TV.

Downloaded from www.Manualslib.com manuals search engine

What to Expect

The next time you turn on your TV, the GUIDE Plus+ system will appear on the screen. The following examples explain what you might see:

- If all of the program information has been sent to your TV, the GUIDE Plus+ system appears with all of your TV program listings.
- If the program information hasn't been sent to your TV yet, an outline of the GUIDE (without TV program listings) will appear on the screen. Program information is usually sent to your TV at night.
- If the TV detected that you have multiple cable companies in your area, *STEP 5: Choosing Your Channel Lineup* appears.

Features of the GUIDE Plus+ system are explained in Chapter 3.

To clear the guide from your screen, press CLEAR or GUIDE on the remote control.

Next Steps

Now that you've finished the Interactive Setup, you're ready to watch TV. This might be a good time to program your remote control. The remote control that came with this TV can be programmed to operate other components. Go to the next chapter to find out how to program your remote.

Downloaded from www.Manualslib.com manuals search engine

Chapter 2

Using the Remote Control

Chapter Overview:

- The Buttons on the Remote Control
- Programming the Remote to Operate Other Components
- How To Use the Remote After You've Programmed It
- Code List

Downloaded from www.Manualslib.com manuals search engine



The Buttons on the Remote Control

0-9 (Number buttons) Enter channel numbers and time settings directly through the remote control.

To enter a two-digit channel, press the two digits. To enter a three-digit channel, press and hold the first digit for two seconds until two dashes appear to the right of the number, then add the second two. Example: to tune to channel 123, press and hold 1 for two seconds, press 2, then press 3.

Arrow buttons (up, down, left, right) Press the arrow buttons to move through the on-screen menu system. Also moves PIP window to different areas on the screen.

ANTENNA Functions as TV/VCR button in VCR mode and TV/receiver button in SAT•CABLE mode.

AUX (auxiliary) Puts the remote in auxiliary mode to operate the component you've programmed the remote to operate with this button. You can program this button to control a cable box, most RCA, GE and PROSCAN audio components, a laserdisc player, or a VCR. If you set up the Auto Tuning feature (Chapter 3), pressing the AUX button automatically tunes the TV to the correct channel.

CH (up and down) buttons Scan up or down through the current channel list. Press once to change the channel up or down; press and hold to continue changing channels.

CH CTRL (Channel Control) Selects the picture window (main window or PIP window) that changes when you press the channel up or channel down button or the WHO•INPUT button.

CLEAR Removes any menu or display from the screen and returns you to TV viewing.

DVD Puts the remote in DVD mode. If you set up the Auto Tuning feature (Chapter 3), pressing the DVD button automatically tunes the TV to the correct channel.

FORWARD If you're operating a VCR or DVD Player with the remote control, press FORWARD to advance a disc or videotape.

GO BACK Returns you to the previous channel.

GUIDE Press GUIDE to make the GUIDE Plus+ system appear on the screen: press GUIDE again to remove it from the screen.

INFO Displays channel information.

L.E.D. (light-emitting diode) The little light on the remote that lights when you are programming the remote. It also lights when you press a valid button on the remote.

MENU Displays the TV's Main menu. You can also press and hold for 2 seconds to display the GUIDE Plus+ system.

MUTE Lowers the volume to its minimum level. Press again to restore volume.

OK When a menu is on the screen, press OK to select the item that is highlighted.

Downloaded from www.Manualslib.com manuals search engine

Tip

To turn off all the RCA, GE, and PROSCAN components that are connected to the TV, press ON•OFF twice within two seconds.

This feature only works with most RCA, GE and PROSCAN products.

ON•OFF Turns the TV on and off. When the remote is in another mode (VCR, DVD, Satellite, etc.) and the remote is programmed to operate that component, you can press ON•OFF to turn the component on and off.

PAUSE If you're operating a VCR or DVD Player with the remote control, press PAUSE when the disc or videotape is playing to pause playback.

PIP (Picture-In-Picture) Brings up the small Picture-In-Picture window. Press again to remove the PIP window.

PLAY If you're operating a VCR or DVD Player, plays the disc or videotape.

REC•VCR+ When the GUIDE Plus+ program guide is on the screen, press REC•VCR+ to program your VCR to record a program. If the remote is in VCR mode, press REC•VCR+ to start recording.

RESET Resets original settings in several control panels.

REVERSE If you're operating a VCR or DVD Player with the remote control, press REVERSE to go backwards on a disc or videotape.

SAT•CABLE Puts the remote in SAT•CABLE mode. If you set up the Auto Tuning feature (Chapter 3), pressing the SAT•CABLE button automatically tunes the TV to the correct channel.

SKIP If you press this button before you change the channel, the TV waits 30 seconds and automatically goes back to the original channel. Each time you press SKIP, you add 30 seconds (i.e, if you press SKIP two times before you change the channel, the TV waits 60 seconds and automatically turns back to the original channel).

SOUND Displays the *AUDIO PROCESSOR* menu.

STOP If you're operating a VCR or DVD Player, stops playing the disc or videotape.

SWAP Switches the main picture with the PIP window.

TV Turns on the TV and puts the remote in TV mode. Also displays channel information.

VCR1 Puts the remote in VCR mode. If you set up the Auto Tuning feature (Chapter 3), pressing the VCR1 button automatically tunes the TV to the correct channel.

VCR2 Puts the remote in VCR mode. If you set up the Auto Tuning feature (Chapter 3), pressing the VCR2 button automatically tunes the TV to the correct channel.

VOL (up and down) buttons Decrease or increase the TV's volume.

WHO•INPUT In TV mode, press WHO•INPUT to toggle through the available Video Input channels (VID/SVID and the current channel). In SAT mode, press to select available channel lists.

Using the WHO•INPUT Button

Use the WHO•INPUT button to toggle through the available input sources (VID and the current channel) and view the content from the component you have connected to the TV.

1. Press TV to place the remote in TV mode. Make sure that the content from the component is turned ON.
2. Press WHO•INPUT to tune to the available input source and view the component.
3. Press WHO•INPUT again to tune back to the channel you were previously watching.

Downloaded from www.Manualslib.com manuals search engine



You'll use these buttons when you program the remote to operate another component.

The remote may not operate all models of all brands.

Programming the Remote to Operate Other Components

The universal remote control can be programmed to operate most brands of remote controllable VCRs, satellite receivers and cable boxes. The remote is already programmed to operate most RCA, GE and PROSCAN TVs, VCRs, DVD players, laserdisc players and satellite receivers.

Find Out If You Need to Program the Remote

To determine whether the universal remote needs to be programmed, turn a component ON, such as a VCR, point the remote at the VCR, and press the VCR1 button. Then press ON•OFF or channel up or channel down to see if the VCR responds to the remote commands. If not, the remote needs to be programmed.

How to Program the Remote

There are two ways to program the remote control: automatic code search and direct entry. Instructions for both ways follow.

Using Automatic Code Search

1. Turn on the component you want the remote to operate (VCR, DVD Player, etc.)
2. Press and hold the component button on the remote control that corresponds to the component you want the remote to operate (VCR1, DVD, etc.). While you hold down the component button, press and hold ON•OFF (when the red light on the remote turns on, release both buttons).
3. Press PLAY (the red light on the remote, located below the ON•OFF button, starts flashing).

   The remote is searching the first set of component codes (there are 20 sets of codes). If the component you want to operate doesn't turn off automatically after 5 seconds, press PLAY again (the red light starts flashing again as the remote searches through the next set of codes).

   Continue pressing PLAY until the component turns off.

   Note: *If the component doesn't turn off after you've pressed the PLAY button 20 times, the component can't be programmed.*
4. Press REVERSE, wait 2 seconds. Repeat this step until the component turns back on.
5. To finish, press and hold the STOP button until the red light on the remote turns off.

Tip

To stop the automatic code search without programming any components, press and hold CLEAR until the light on the remote turns off.

Downloaded from www.Manualslib.com manuals search engine

Using Direct Entry

1. Turn on the component you want the remote to operate.
2. Look up the brand and code number(s) for the component on the code list on page 26.
3. Press and hold the component button that corresponds to the component you want the remote to operate (VCR1, DVD, etc.)
4. Enter the code from the code list.
5. Release the component button.
6. Press ON•OFF to see if the component responds to the remote commands. If it doesn't, try pressing the component button and then ON•OFF again.
7. If you get no response, repeat these steps using the next code listed for your brand until the component responds to the remote commands.

How to Use the Remote After You've Programmed It

Tip

The buttons might operate differently for other components, especially when you're using another component's menu system.

Once the remote has been programmed successfully, you are ready to use it to control your components. To operate the component:

1. Press the component button (TV, VCR1, VCR2, DVD, AUX, or SAT•CABLE) to set the remote to operate the component.
2. Press ON•OFF to turn the component ON or OFF.
3. Use the remote buttons that apply to that component.

   Note: *If you keep pressing buttons and nothing happens, the remote is probably in the wrong mode. You must press the component button that matches the component you want to operate (i.e., if you want to operate the VCR, press VCR1 on the remote control to put the remote in VCR mode.)*

Downloaded from www.Manualslib.com manuals search engine

VCR

Admiral 2131
Adventura 2026
Aiko 2027
Aiwa 2002, 2026
Akai 2003, 2004, 2005, 2007, 2008, 2111,2112, 2113
American High 2021
Asha 2013
Audio Dynamics 2009, 2010
Audiovox 2014
Bell & Howell 2011
Beaumark 2013
Broksonic 2012, 2025
Calix 2014
Candle 2013, 2014, 2015, 2016, 2017, 2018, 2019
Canon 2021, 2022, 2114
Capehart 2020, 2110
Carver 2062
CCE 2027, 2061
Citizen 2013, 2014, 2015, 2016, 2017, 2018,2019,2027
Colortyme 2009
Colt 2061
Craig 2013, 2014, 2023, 2061
Curtis-Mathes ..... 2000, 2002, 2009, 2013, ... 2016, 2018, 2021, 2022, 2024, 2115
Cybernex 2013
Daewoo . 2015, 2017, 2019,2025, 2026, 2027, 2028, 2110
Daytron 2110
Dbx 2009, 2010
Dimensia 2000
Dynatech 2002, 2026
Electrohome 2014, 2029
Electrophonic 2014
Emerson ..... 2002, 2012,2014, ... 2015, 2021, 2024, 2025,2026,2029, 2030, 2032, ... 2033, 2034, 2035, 2036, 2037, 2038, 2039, 2040, 2041, ... 2042, 2044, 2045, 2047, 2065, 2105, 2113, 2116, 2117, 2130
Fisher 2011, 2023, 2048, 2049, 2050, 2051, 2052,2118
Fuji 2021, 2119
Funai 2002, 2026
Garrard 2026
GE 2000, 2001, 2013, 2021, 2022, 2053, 2115, 2120
Goldstar 2009, 2014, 2018, 2054, 2121
Gradiente 2026
Harley Davidson 2026
Harman Kardon 2009
Harwood 2061
Headquarter 2011
Hitachi .. 2002, 2055, 2056, 2057, 2107, 2111, 2120, 2122
HI-Q 2023
Instant Replay 2021
JCL 2021
JC Penney ..... 2009, 2010, 2011, 2013, 2014, 2021, ... 2022, 2055, 2056, 2058, 2059, 2060, 2107, 2118
Jensen 2055, 2056, 2111
JVC 2009, 2010, 2011, 2018, 2058, 2111, 2123
Kenwood 2009, 2010, 2011, 2016, 2018, 2058, 2111,2123
KLH 2061
Kodak 2014, 2021
Lloyd 2002, 2026
Logik 2061
LXI 2014
Magnavox 2021, 2022, 2062, 2063, 2104, 2108, 2124
Magnin 2013
Marantz ..... 2009, 2010, 2011, ... 2016, 2018, 2021, 2058, 2062,2064
Marta 2014
Masushita 2021
MEI 2021
Memorex ..... 2002, 2011, ... 2013, 2014, 2021, 2023, 2026, 2104, 2131
MGA 2029, 2065, 2113
MGN Technology 2013
Midland 2053
Minolta 2055, 2056, 2107
Mitsubishi ..... 2029, 2055, 2056, 2065, 2066, 2067, 2069, ... 2070, 2071, 2072, 2073, 2074, 2106, 2113, 2123
Montgomery Ward 2075, 2131
Motorola 2021,2131
MTC 2002, 2013, 2026
Multitech 2002, 2013, 2016, 2026, 2053, 2061
NEC ..... 2009, 2010, 2011, 2016, 2018, ... 2058, 2064, 2076, 2078, 2079, 2111, 2123
Nikko 2014
Noblex 2013
Olympus 2021
Optimus 2014, 2131
Optonica 2096
Orion 2035
Panasonic 2021, 2022, 2109, 2125, 2126, 2127
Pentax 2016, 2055, 2056, 2107, 2120
Pentex Research 2018
Philco 2021, 2022, 2062, 2063
Philips 2021, 2062, 2096, 2124
Pilot 2014
Pioneer 2010, 2055, 2080, 2081, 2123
Portland 2016, 2017, 2019, 2110
ProScan 2000, 2001
Protec 2061
Pulsar 2104
Quarter 2011
Quartz 2011
Quasar 2021, 2022, 2125
RCA ..... 2000, 2001, 2003, 2013, 2021, ... 2055, 2056, 2082, 2083, 2084,2085, 2086,2087, ... 2088, 2089, 2090, 2091, 2107, 2115, 2120, 2125
Radioshack/Realistic ..... 2002, 2011, 2013, 2014 ... 2021, 2022, 2023, 2026, 2029, 2049, 2050, 2096, 2131
Radix 2014
Randex 2014
Ricoh 2128
Runco 2104
Samsung 2005, 2013, 2015, 2033, 2053, 2112
Sanky 2131, 2104
Sansui 2010, 2092, 2111, 2123
Sanyo 2011, 2013, 2023
Scott 2012, 2015, 2025, 2032, 2035, 2038, 2065, 2093, 2116
Sears ..... 2011, 2014, 2021, 2023, 2048, ... 2049, 2050, 2051, 2055, 2056, 2107, 2118
Sharp 2002, 2017, 2029, 2094, 2095, 2096, 2131
Shintom 2004, 2056, 2061, 2098
Shogun 2013
Signature 2002, 2131
Singer 2021, 2061, 2128
Sony 2002, 2004, 2098, 2099, 2119, 2128
STS 2021, 2107
Sylvania 2002, 2021, 2022, 2026, 2062, 2063, 2065, 2124
Symphonic 2002, 2026
Tandy 2002, 2011
Tashiko 2014
Tatung 2058, 2111
TEAC 2002, 2026, 2058, 2085, 2111
Technics 2021, 2109
Teknika 2002, 2014, 2021, 2026, 2100, 2129
TMK 2013, 2024, 2047
Toshiba 2015, 2049, 2051, 2055, 2065, 2093, 2116
ToteVision 2013, 2014
Unitech 2013
Vector Research 2009, 2010, 2015, 2016
Victor 2010
Video Concepts 2009, 2010, 2015, 2016, 2113
Videosonic 2013
Wards ..... , 2002, 2013, 2014, 2015, 2021, 2023, 2026, ... 2029, 2055, 2056, 2061, 2096, 2101, 2102, 2103, 2107, 2116, 2131
XR-1000 ..... 2021, 2026, 2061
Yamaha 2009, 2010, 2011, 2018, 2058, 2111
Zenith 2004, 2098, 2104, 2119, 2128

Cable Boxes

ABC 5002, 5003, 5004, 5005, 5006, 5007, 5053
Antronix 5008, 5009
Archer 5008, 5009, 5010, 5011
Cabletenna 5008
Cableview 5008
Century 5011
Citizen 5011
Colour Voice 5012, 5013
Comtronics 5014, 5015
Contec 5016
Eastern 5017
Garrard 5011
GC Electronics 5009
Gemini 5018, 5019, 5049
General Instrument 5003
Hamlin 5020, 5021, 5022, 5035, 5045
Hitachi 5003
Hytex 5002
Jasco 5011
Jerrold ... 5003, 5005, 5007,5018, 5023, 5024, 5046, 5053
Magnavox 5025
Memorex 5026
Movie Time 5002, 5027, 5028
NSC 5002, 5027, 5028
Oak 5002,5016, 5029
Panasonic 5048, 5052
Paragon 5026
Philips 5011, 5012, 5013, 5019, 5025, 5030, 5031, 5032
Pioneer 5033, 5034
Pulsar 5026
RCA 5047, 5049, 5052
Realistic 5009, 5049
Regal 5022, 5035
Regency 5017
Rembrandt 5003
Runco 5026
Samsung 5014, 5034
Scientific Atlanta 5006, 5036, 5037, 5038
Signal 5014, 5018
Signature 5003
SL Marx 5014
Sprucer 5052
Starcom 5007, 5018, 5053
Stargate 5014, 5018
Starquest 5018
Tandy 5040
Teleview 5014
Tocom 5004, 5023, 5041
Toshiba 5026
Tusa 5018
TV86 5027
Unika 5008, 5009, 5011
United Artists 5002
United Cable 5053
Universal 5008, 5009, 5010, 5011
Videoway 5044
Viewstar 5015, 5025, 5027, 5040
Zenith 5026, 5050, 5051

Satellite Receivers

Chapparal 5056, 5057
Drake 5058, 5059
GE 5000
General Instruments 5060, 5061, 5062
Panasonic 5075
Primestar 5076
ProScan 5000
RCA 5000
Realistic 5063
Sony 5072
STS1 5064
STS2 5065
STS3 5066
STS4 5067
Toshiba 5068
Toshiba 5073
Uniden 5069

Downloaded from www.Manualslib.com manuals search engine

Using the TV's Features

Chapter Overview:

- All About the GUIDE Plus+ System
- The Channel Banner
- PIP (Picture-In-Picture)
- Auto Tuning
- Parental Controls and V-Chip

Changing Entertainment. Again.

Downloaded from www.Manualslib.com manuals search engine

About the GUIDE Plus+ System

The GUIDE Plus+ system is an interactive on-screen program guide that lists TV schedules for your area and allows your TV direct control of a cable box and/or VCR. You must first set up the GUIDE Plus+ Menu system in order to view this on-screen program guide (see Chapter 1 for details). Press GUIDE to bring up the GUIDE Plus+ system.

There are six sections of the GUIDE Plus+ system:

- A row of Action buttons at the top of the screen *(1, 2* and *3)*
- Program information
- A row of menu options *(Grid, Sort, News, Schedule, Messages, Channels, Setup)*
- Channel listings
- Promotional information
- Video window

Note: *The GUIDE Plus+ system screens illustrated in this book are representations of what you are likely to see. Not all channels, programs, and GUIDE Plus+ information depicted will be available in your area.*

New features and options can be downloaded to the GUIDE Plus+ system, so these too are subject to change.

Tip

Since the program information provided by the GUIDE Plus+ system is based on your locale, you will need to run Setup again if you move to a different zip or postal code.

Downloading Data

The GUIDE Plus+ system is not available until it completes its first download of program listings. When the power is turned off, the TV locates a "host channel" that carries GUIDE Plus+ system data containing program schedule and channel lineup information. A channel lineup is the list of stations and their respective channels.

To ensure that your first download of data is complete, you should leave your TV off overnight. Downloads occur several times a day. The TV must be turned off for GUIDE Plus+ system data to download.

If the TV loses power or is unplugged, GUIDE Plus+ system program listings may be lost. When power is restored, make sure the setup information is still correct. The GUIDE Plus+ system will receive updated program information during the next scheduled download.

Channel Lineup

If more than one cable company services your area, you may be prompted with *STEP 5: Choosing Your Channel Lineup* after the first GUIDE Plus+ system download. You will need to identify your cable company by selecting the correct channel numbers for the stations in question.

- Use the up and down arrow buttons to change the channel group and press OK when the correct channel group is highlighted.

Downloaded from www.Manualslib.com manuals search engine



Press GUIDE on the remote control to see the GUIDE Plus+ system. To remove the program guide from the screen, press OK, GUIDE, or CLEAR.

Getting In & Out of the GUIDE Plus+ System

To enter the GUIDE Plus+ system:

- Press GUIDE on the remote.
- Press and hold MENU for 2 seconds on the front panel.

To exit the GUIDE Plus+ system:

- Highlight a program and press OK to exit the GUIDE Plus+ system and tune to the channel.
- Press GUIDE to exit the GUIDE Plus+ system and tune to the channel displayed in the video window.
- Press CLEAR to exit the GUIDE Plus+ system and return to the original channel.

The GUIDE Plus+ System Menus

The GUIDE Plus+ system offers seven different options on the Menu bar: *Grid, Sort, News, Schedule, Messages, Channels* and *Setup*. To access the Menu bar:

1. Press GUIDE to access the GUIDE Plus+ system.
2. Press MENU or use the up and down arrow buttons to select the Menu bar (the Grid Guide appears by default).
3. Use the left and right arrow buttons to access other menus.
4. Press OK, or MENU, or use the down arrow button to see the menu options.

10:06pm
1 Watch 2 Go To 3 Record
Late Night with Conan O'Brien: actor Stephen Baldwin; author mark Leyner; comedian Robert Schimmel; the Brian Setzer Orchestra
NBC (7) 10:00pm (3 hr) CC
Grid Sort News Schedule
Wed 10:00pm 10:30pm
Last Channel
The Nanny Everybody L...
Spin City Dharma & Gr...
Fox Beverly Hills 90210
CBS The Nanny Everybody L...
Late Night wi... Working
Gone With the Wind
Good Morning, Vietnam
PBS Mark Russell Great Perfor...
Big Show
Dateline
Air Force One retires
Mon. at 10:00
TODAY
Weekdays 7am

Grid Guide

The Grid Guide appears each time you enter the GUIDE Plus+ system. It displays the current programming for each channel. The current program is displayed in the video window.

- Press the up and down arrow buttons on the remote to browse channel listings and the channel up and down buttons to page through the listings. Use the right and left arrow buttons to browse future program listings.
- To tune to a channel, highlight the program you want to view in the channel listing and press OK. Press CLEAR to exit the GUIDE Plus+ system and return to the original channel. Press GUIDE to exit the GUIDE Plus+ system and tune to the channel in the video window.

Then use the Grid Guide Action Buttons as described next.

Downloaded from www.Manualslib.com manuals search engine



Grid Guide Action Buttons

Action buttons will change according to where you are in the GUIDE Plus+ system. Be sure to look at the action bar before pressing the command numbers.

When highlighting the program, the following Action buttons appear:

- ***Watch*** Press 1 on the remote to place a timer in the Schedule for the TV to turn on and tune to the program highlighted in the channel listing. When the TV turns on, the GUIDE Plus+ system will automatically appear with the scheduled program highlighted and tuned in the video window.
- ***Go To*** Press 2 on the remote to bring up the direct dial box and enter the number of the channel you want. Press OK to highlight the channel and current program in the channel listing of the Grid guide. Press OK again to tune to the highlighted channel. If the video window is unlocked, it will automatically tune to the channel.
- ***Record*** Press 3 on the remote to place a timer in the Schedule for the VCR to record the program highlighted in the channel listing.

  If you have a cable box, changing channels on the TV will not cause the cable box channel to change while recording.

  Record will only appear if you have set up the GUIDE Plus+ system and specified your VCR type.

The program information window will display a confirmation when you have successfully scheduled a program to watch or record.

> ***Note:*** *If you have selected two programs to watch or record which begin at the same time or overlap, you will receive a timer conflict message. You must choose between the two programs.*

When highlighting the Channel names (the left column on the channel listing), the following Action buttons appear:

- ***Lock/Unlock*** Press 1 to lock or unlock the video window to either stay at one channel as you browse the GUIDE Plus+ system (lock) or change as you browse through different channels (unlock).
- ***Go To*** Press 2 on the remote to bring up the direct dial box and enter the number of the channel you want. Press OK to highlight the channel and current program in the channel listing of the Grid Guide. If the video window is locked, press OK to tune to the highlighted channel. If the video window is unlocked, it will automatically tune to that channel.

Tip

Press the PIP button to lock or unlock the video window when the GUIDE Plus+ system is on the screen.

Downloaded from www.Manualslib.com manuals search engine



Sort

The *Sort* menu lets you browse programs by category. The channel to which you are currently tuned is displayed in the video window.

To Sort:

1. If the GUIDE Plus+ system isn't on your screen, press GUIDE on your remote control.
2. Press MENU on the remote to select the Menu bar.
3. Use the arrows to highlight *Sort*. When *Sort* is highlighted for the first time, the *Movies* category is displayed. Thereafter, the last category used becomes the default. A listing of subcategories is displayed below the category name. Use the left and right arrows to highlight other categories.
4. Use the up and down arrow buttons to highlight a subcategory. For example, highlight *All* and press OK (the GUIDE Plus+ system sorts the programs).
5. Press the up and down arrow buttons to review the list one program at a time. Press the channel up and down to review the list one page at a time.
6. Select MENU to return to the menu bar, or press GUIDE or CLEAR to exit the GUIDE Plus+ system.

Then use the Sort Menu Action Buttons as described next..

Sort Menu Action Buttons

When viewing the results of a Sort, the following Action buttons appear:

- ***Watch*** Press 1 on the remote to place a timer in the Schedule, and then follow the on-line help for further options. Placing a timer in the Schedule will cause the TV to turn on and tune to the program highlighted in the Channel listing at the predetermined time.
- ***Record*** Press 3 on the remote to set the VCR to record the program highlighted in the channel listing. If you have a cable box, changing TV channels will not cause the cable box channel to change while recording.

The program information window will display a confirmation when you have successfully scheduled a program to watch or record.

> ***Note:*** *If you have selected two programs to watch or record which begin at the same time or overlap, you will receive a timer conflict message. You must choose between the two programs.*
>
> ***Note:*** *Be sure that during the GUIDE Plus+ system setup you specified that you have a VCR. If you didn't, the RECORD option will not be available.*

Downloaded from www.Manualslib.com manuals search engine

News

The *News* menu lets you browse current news stories by headline.

1. If the GUIDE Plus+ system isn't on your screen, press GUIDE on your remote control.
2. Press MENU on the remote control to select the menu bar.
3. Use the arrows to highlight *News* (if MSNBC is available on your TV, it will appear in the video window).
4. Use the up and down arrows to highlight a story.
   - Use the up and down arrows to browse the list one story at a time.
   - Use the channel up and down to browse through the list one page at a time.
5. Press the right arrow button to see full text.
6. If there are multiple pages of text, press the right or left arrow button to page forward or back through the pages of text. Press the down arrow to view the next story.
7. Select MENU to return to the Menu bar, or press GUIDE or CLEAR on the remote to exit the GUIDE Plus+ system.

Schedule

The *Schedule* menu allows you to alter timers for either viewing or recording programs. The GUIDE Plus+ system allows one-touch VCR recording if you have connected the G-LINK cable to your VCR. See Chapter 1 for more details on connecting the G-LINK cable.

To schedule a program to watch or record:

1. If the GUIDE Plus+ system isn't on your screen, press GUIDE on your remote control.
2. Press MENU on the remote to select the Menu bar.
3. Highlight a program within the Channel listing.
4. Select *Watch* or *Record* from the Action buttons bar. The timer is then automatically logged into the *Schedule* menu.
5. If you select *Record*, make sure to place a blank tape in the VCR and turn it off.

   Note: *If you have a cable box connected to your TV and VCR, tune your VCR to the cable box output channel prior to turning off the VCR.*

The program information window will display a confirmation when you have successfully scheduled a program to watch or record.

Note: *If you have selected two programs to watch or record which begin at the same time or overlap, you will receive a timer conflict message. You must choose between the two programs.*

Downloaded from www.Manualslib.com manuals search engine

To remove or change the frequency (daily, once, or weekly) of a scheduled event, access the *Schedule* menu from the Menu bar.

1. Press GUIDE to bring up the GUIDE Plus+ system.
2. Press MENU on the remote to select the Menu bar.
3. Use the arrows to highlight the *Schedule* menu selection.
4. Use the up and down arrows to highlight the program you want to edit.

Then use the Schedule Menu Action Buttons as described next.

Schedule Menu Action Buttons

When viewing the *Schedule* menu the following Action buttons appear:

- ***Remove*** Highlight the *Watch* or *Record* timer you wish to remove from the schedule and press 1 on the remote.
- ***Change*** Highlight the *Watch* or *Record* timer you wish to change and press 3 on the remote to toggle the frequency between the following choices:

  DAILY records the same program each day Monday through Friday.

  ONCE records only on that day.

  WEEKLY records the program each week at the same time.



Messages

Occasionally you will receive messages regarding your GUIDE Plus+ system, as well as special programming information. You can access these messages from the *Messages* menu on the Menu bar.

To read messages:

1. If the GUIDE Plus+ system isn't on your screen, press GUIDE on your remote control.
2. Press MENU on the remote to select the Menu bar.
3. Use the arrows to highlight the *Messages* menu selection.
4. Highlight the message you want to read by using the up and down arrow buttons.
5. Press INFO to display the full text of the message. If the text continues beyond the screen, press INFO to view the next page of text. Once you have reached the end of the message, press INFO to close the expanded information and return to the *Messages* screen.

Then use the Messages Menu Action Button as described next.

Messages Menu Action Button

When viewing the *Messages* menu the following Action button appears:

- ***Remove*** Highlight the message you want to delete and press 1 on the remote.

Downloaded from www.Manualslib.com manuals search engine

Channels

You can customize the channel listing by enabling or disabling the display of certain channels. For instance, you may disable channels that you never watch. You can restore disabled channels at a later point in time.

1. If the Guide Plus+ system isn't on your screen, press GUIDE on your remote control.
2. Press MENU to select the Menu bar.
3. Use the right and left arrows to highlight the *Channels* menu selection.
4. Use the up and down arrows to select a channel.

Then use the Channels Menu Action Buttons as described next.

Channels Menu Action Buttons

While browsing the *Channels* menu, the following Action buttons appear:

- ***Cancel*** Press 1 on the remote to cancel any changes you made since entering the *Channels* Menu.
- ***Change*** Press 2 on the remote to change the channel number for the highlighted channel line.
- ***On/Off*** Press 3 on the remote to toggle the state of the channel between *On* and *Off*.

Setup

The *Setup* menu allows you to access the GUIDE Plus+ system setup information. To access the Setup option:

1. If the Guide Plus+ system isn't on your screen, press GUIDE on your remote control.
2. Press MENU to select the Menu Bar.
3. Use the right arrow to highlight the *Setup* menu selection.
4. Use the up and down arrows to select *Change system settings*, *Review options*, or *View demo*.

   - ***Change system settings*** Confirms the settings you completed in the GUIDE Plus+ system setup are correct.
   - ***Review options*** Displays the GUIDE Plus+ auto display options.

     On Automatically displays the GUIDE Plus+ system when you press the ON•OFF button on the remote control.

     Off Disables the GUIDE Plus+ system from being displayed when you press the ON•OFF button on the remote control.
   - ***View demo*** Runs the GUIDE Plus+ system demonstration.

Note: *If you have not completed your GUIDE Plus+ system setup, these options will not be available. A screen will prompt you to complete your setup.*

Downloaded from www.Manualslib.com manuals search engine

10:06pm
1 Watch 2 Go To 3 Record
Late Night with Conan O'Brien: actor Stephen Baldwin; author mark Leyner; comedian Robert Schimmel; the Brian Setzer Orchestra
NBC [7] 10:00pm (3 hr)
Grid Sort News Schedule
Wed 10:00pm 10:30pm
The Nanny Everybody L...
Spin City Dharma & Gr...
Beverly Hills 90210
The Nanny Everybody L...
Late Night wi... Working
Gone With the Wind
Good Morning, Vietnam
Mark Russell Great Perfor...
Big Show
Air Force One retires
Mon. at 10:00
TODAY
Weekdays 7am

Promotional information

How to Get More Information About an Advertisement or a Program

To find out more information about a program, advertisement or special, use the left arrow button to highlight the channel listing or promotional information box.

Requesting more information about a particular show displays the PlusCode programming number and the *Shows on Next* for that channel.

Press the INFO button to exit the expanded information screen.



GUIDE Plus+ Menu Items

The *GUIDE Plus+ Menu* gives you access to features in the GUIDE Plus+ system. To access the *GUIDE Plus+ Menu*:

1. Press MENU on the remote.
2. Highlight *GUIDE Plus+ Menu* and press OK.

Each menu and the sub-menus are listed below:

GUIDE Plus+ Setup Displays the GUIDE Plus+ system setup screen.

> ***Change system settings*** Confirms the settings you completed in the GUIDE Plus+ system setup are correct.
>
> ***Review options*** Displays GUIDE Plus+ system auto display options.
>
> ***View demo*** Runs the GUIDE Plus+ system demonstration.

GUIDE Plus+ Label Displays the GUIDE Plus+ label menu.

> ***On*** Displays the station name when you change channels.
>
> ***Off*** The station name isn't displayed when you change channels.

Continuous Demo Runs the GUIDE Plus+ system demonstration until it is turned off. To turn off the demonstration you must turn off the TV.

> ***Note:*** *If you have not completed your GUIDE Plus+ system setup, these options will not be available. A screen will prompt you to complete your setup.*

Downloaded from www.Manualslib.com manuals search engine



Sample displays on a Channel Banner.

Channel Banner

There are several indicators that might appear when you press the TV or INFO buttons on the remote. This display is called the Channel Banner. The following list describes the items on the Channel Banner screen (left to right and top to bottom).

12:01	Displays the current time.
	The lock is displayed to indicate when the Parental Controls are locked or unlocked.
	Displayed when Closed Captioning is available on the current channel.
ESPN	Displays the label assigned to the current channel.
60	Displays the current channel or input channel.
	Mute is displayed when you mute the audio.
	Stereo is displayed when the current channel is broadcasting in Stereo.
SAP	Displayed when the current channel is broadcasting SAP (Second Audio Program) information.
PIP VID	Displays the current PIP channel.
	Displayed when the Sleep Timer has been set.
00:00	Displayed to count down time left on the commercial skip (SKIP) timer.

The PIP (Picture-In-Picture) Feature

The PIP (Picture-In-Picture) feature lets you display a second, smaller picture on top of the main picture.

Important: Your TV has a single tuner that tunes to cable or off-air television channels. In order for the second picture (the PIP picture) to appear on the screen, you must connect another component (like a satellite receiver or VCR) to the TV. You need to use audio/video cables to connect the component to the TV. Go to the connections on pages 8 or 9 for more information.



How To Use PIP

While you can use PIP in different ways, this basic PIP scenario should get you started. While watching the TV, follow these steps to use your VCR to supply the picture for PIP.

1. The TV must be on. Tune to the channel you want to watch.
2. Press the PIP button on the remote (the PIP picture appears with the same picture in it as the main picture).

Downloaded from www.Manualslib.com manuals search engine



3. Turn on the VCR.
4. If the picture gets fuzzy, press the TV/VCR button on the VCR.
5. To see a different picture in the PIP window:
   - Press the TV button on the remote control.
   - Press the WHO•INPUT button on the remote until you see the picture that's coming from the VCR (*PIP VID* appears on the screen).
6. To change the picture in the PIP window, you need to change the channel on the VCR because the VCR is the second signal source.

   Press the channel buttons on the VCR or on the VCR's remote control.
7. To change the channel in the main picture, press CH CTRL until the main channel number appears highlighted (yellow). Press the channel up or down button on the remote control.

   Note: *Channel up and down won't work correctly when the VID channel is highlighted (yellow).*



The buttons on the remote control that operate the PIP feature include: the four arrow buttons, CH CTRL, PIP, and SWAP.

PIP Buttons: General Explanation

The buttons on the remote control that you'll use for the PIP feature are explained below:

PIP Press the PIP button to make the PIP window appear on the screen. Press PIP again to remove the window.

Note: *If you selected Alternate with PIP button in the PIP Closed-Caption Display menu, press the PIP button when the PIP window is on the screen to see closed-captioning in the PIP window.*

Arrow buttons (left, right, up, and down) Move the PIP window to different areas of the screen.

CH CTRL (channel control) Lets you switch channel control between the PIP window and the main picture. To determine whether the remote control is the PIP picture or the main picture, look at the TV screen: the yellow channel number is the one you are controlling. Press CH CTRL to change which picture you're controlling.

SWAP Switches, or "swaps," where the two pictures appear on the TV screen. The smaller PIP picture swaps to the main screen and the main picture goes to the little PIP window.

Downloaded from www.Manualslib.com manuals search engine



You must use audio/video cables to connect your VCR to your TV in order for PIP to work.



TV channel
PIP channel (VID) is from VCR

To change the PIP channel, press the channel buttons on the VCR. To change the TV channel, press CH CTRL until the TV channel is highlighted (yellow) and press the CH up and down buttons.

PIP Troubleshooting

- The PIP feature on this TV only works if you connect a second video source (like a VCR or satellite receiver), to your TV with audio/video cables. If you use a cable box, you may need extra equipment. Contact your cable company and/or go to page 12 for more details about a cable box connection.
- Swap won't work? Make sure the remote is in the right mode. For example, once you turn on the VCR with the VCR1 button, you can't SWAP the pictures until you put the remote in TV mode. Just press the TV button.
- No signal or bad reception? Most VCRs and satellite receivers have an antenna or TV/VCR button. Press the antenna or TV/VCR button on the front of the component.

  Note: *If you programmed the Universal remote control to operate your VCR, the ANTENNA button on the remote acts as a TV/VCR button.*
- Every time you change channels, the same channel appears in both windows (the main picture and the PIP picture).

  A. Press the CH CTRL button on the remote until the TV picture channel number is highlighted (yellow). The channel buttons on your remote control won't work correctly for PIP when the *VID* channel is highlighted (yellow).

  B. The only way to successfully change channels for the picture that is coming from the channel on your VCR (the *VID* channel), is to press the channel buttons on the VCR or on the VCR's remote control.



With the auto tuning feature, you can set up the TV to tune to the channel you need to watch by pressing that component's button.

Why You Should Use the Auto Tuning Feature

The auto-tuning feature automatically tunes the TV to the correct channel for different components you have connected to your TV (like a VCR, DVD Player, etc.) When you set up auto tuning in the menu system you don't have to remember to change your TV to channel 3, for example, when you want to watch the tape in your VCR.



How to Set Up the Auto Tuning Feature

The way you set up the auto tuning feature in the TV's menu corresponds to the component buttons on the remote and the way you have each component connected to your TV. When you set auto tuning, you're telling the TV what channel to tune to when you press the VCR1, VCR2, DVD, or SAT•CABLE button on the remote control.

1. Press MENU (the *TV MAIN MENU* appears).
2. Highlight *Channel* and press OK on your remote control.
3. Highlight *Auto Tuning* and press OK.

Downloaded from www.Manualslib.com manuals search engine

4. Choose which channel you would like to set:

   Set VCR 1 Channel Displays a list that lets you set up the channel that the TV tunes to when you press the VCR1 button on the remote.

   Set VCR 2 Channel Displays a list that lets you set up the channel that the TV tunes to when you press the VCR2 button.

   Set DVD Channel Displays a list that lets you select the channel that the TV tunes to when you press the DVD button.

   Set SAT/CABLE Channel Displays a list that lets you set up the channel that the TV tunes to when you press SAT•CABLE.

5. Highlight the choice that matches the way you have the component connected to this TV, and press OK.



The choices and a brief explanation follow:

Not connected Choose this if you don't have this particular component connected to the TV, or if you don't want the TV to automatically tune to the correct channel when you're using this component.

Channel 2 **(SAT/CABLE only)** Component (satellite or cable box) is connected to the CABLE/ANTENNA jack on the back of the TV, and you want the TV to tune to channel 2 when you press the SAT• CABLE button on the remote. Reminder: make sure the component's Channel 2/3/4 switch is set to channel 2. Usually this switch is on the back of the component.

Channel 3 Component is connected to the CABLE/ANTENNA jack on the back of the TV, and you want the TV to tune to channel 3 when you press the corresponding button on the remote. Reminder: make sure the component's Channel 3/4 switch is set to channel 3.

Channel 4 Component is connected to the CABLE/ANTENNA jack on the back of the TV, and you want the TV to tune to channel 4 when you press the corresponding button on the remote. Reminder: make sure the component's Channel 3/4 switch is set to channel 4.

Video Input Component is connected to the VIDEO jack on the back of the TV and you want the TV to tune to VID (SVID if you used an S-Video cable) Input Channel when you press the component button.

> ***Note:*** *You should choose this for your VCR if you connected it to the TV with audio/video cables.*

Downloaded from www.Manualslib.com manuals search engine



Parental Controls and V-Chip

The *Parental Controls* menu allows you to program your TV so that children cannot see certain programs, channels, or use the front panel controls. The first three choices in the *Parental Controls* menu involve software inside your TV (referred to as V-Chip) which allows you to block TV programs and movies based on violence, sex, or other content you may believe children should not view. In other words, it lets you program your TV so it won't display certain programs.

Once you block programs, you or other adults can unblock programs by entering a password.

By default, the software inside your TV is turned "off," so if you don't want to use this feature, you can just ignore it.

How V-Chip Works

When turned "on," the V-Chip software reads a code that most broadcasters send with programs. That code tells the software the program's age-based rating (TV-MA, TV-14, etc.) and content themes [(Violence (V), Adult Language (L), etc.)]. If you have blocked the rating and/or content themes that the program contains, you will receive the message, "This channel is not approved for viewing," when you tune to that particular channel.

Broadcasters are not required to provide content themes, so programs received with no content themes will only be blocked if you block their age-based rating. You can also block out programs that have been given a rating of "Not Rated," and programs that are considered "unrated" because no code has been sent by the broadcaster. The TV age-based ratings and content themes you can block are listed in the following table.

Downloaded from www.Manualslib.com manuals search engine

Age-Based Rating	Description and Content Themes for Age-Based Ratings
TV-MA	**Mature Audience Only**. Specifically designed to be viewed by adults and may be unsuitable for children under 17. It contains one or more of the following content themes: crude indecent language (L), explicit sexual activity (S), or graphic violence (V).
TV-14	**Parents Strongly Cautioned**. Contains some material that many parents would find unsuitable for children under 14. Parents are strongly urged to exercise greater care in monitoring this program and are cautioned against letting children under the age of 14 watch unattended. This program contains one or more of the following content themes: intensely suggestive dialogue (D), strong coarse language (L), intense sexual situations (S), or intense violence (V).
TV-PG	**Parental Guidance Suggested**. Contains material that parents may find unsuitable for younger children. Many parents may want to watch it with their younger children. The program contains one or more of the following content themes: some suggestive dialogue (D), infrequent coarse language (L), some sexual situations (S), or moderate violence (V).
TV-G	**General Audience**. Most parents would find this program suitable for all ages. It contains little or no sexual dialogue (D) or situations (S), no strong language (L), and little or no violence (V).
TV-Y7	**Directed to Children 7 years and older**. Designed for children ages 7 and above. It may be more appropriate for children who have acquired the developmental skills needed to distinguish between make-believe and reality. Themes and elements in this program may include mild fantasy violence (FV) or comedic violence, or may frighten children under the age of 7.
TV-Y	**All Children**. Themes and elements in this program are designed for a young audience, including children from ages 2-6. It is not expected to frighten younger children.



V-Chip TV Rating Limit

The *V-Chip TV Rating Limit* lets you decide which TV programs can and cannot be viewed.

To set TV programming limits:

1. Choose *Parental Controls* from the Main menu. If Parental Controls have previously been locked, you must enter your password. If they are not locked, you will get a message reminding you that your limits will not be effective until you lock Parental Controls.
2. Press MENU to continue.
3. Highlight and select *V-Chip TV Rating Limit*.
4. Once you get to the *V-Chip TV Rating Limit* screen, use the arrow buttons and OK on your remote to change the status of a TV program rating or content theme from *View* to *Block*.

The following sections give you more details about how to change the status of TV program limits.

Downloaded from www.Manualslib.com manuals search engine

The V-Chip Rating Limit Screen

The following is an example of where items are located within the Rating Limit screen.


V-CHIP TV RATING LIMIT
-- Content --
Rating Status D L S V FV
TV-MA VIEW V V V
Press ^/v to select rating.
Press MENU to exit.
RATING STATUS D L S V FV
TV-MA View V V V
TV-14 View V V V V
TV-PG View V V V V
TV-G View
TV-Y7 View V
TV-Y View

Rating Status Field

Lets you select whether the status of the age-based rating limit to the left is View or Block.

Content Themes

Lists the content themes you can block or view.

Rating Field

Lets you select from a list of age-based ratings you can block or view.

Content Status Fields

Lets you select which content themes to view for the selected rating, and whether the status of the content theme is currently View (V) or Block (B).

Rating Settings Area

Lets you see the current block/view state of age-based ratings and associated content. The View (V) settings are coded in green, and the Block (B) settings are coded in red.


Rating field
Rating status field
Content status fields
V-CHIP TV RATING LIMIT
-- Content --
Rating Status D L S V FV
TV-PG Block B B B B
Press ^/v to view programs with this rating. Press MENU to exit.
RATING STATUS D L S V FV
TV-MA Block B B B
TV-14 Block B B B B
TV-PG Block B B B B
TV-G View
TV-Y7 View V
TV-Y View

Tip

When you change the status of a rating to Block, the system will automatically block higher ratings and all corresponding content themes.

Blocking Age-Based Ratings

You can automatically block all program ratings above a specified age-based rating level. For example, if you only want your child to watch programs that have a TV-G rating and lower (in other words, you want the child to watch TV-G, TV-Y7, and TV-Y), then you need to block out other programming with higher ratings.

To block programs with higher ratings:

1. First, determine the lowest level rating you don't want the child to watch (see chart of age-based ratings on next page).
2. Press the left and right arrow buttons to highlight the *Rating* field.
3. Press the up and down arrow buttons on the remote to scroll through the age-based rating limits. Keep scrolling until the rating corresponding with the lowest rating you do not want the child to watch appears on the screen.

   In the example discussed above, you would scroll through the *Rating* field until TV-PG appears, since the highest rating you want the child to watch is TV-G.

Downloaded from www.Manualslib.com manuals search engine

Hierarchy of Age-Based Ratings	
TV-MA	*Mature Audience Only*
TV-14	*Parents Strongly Cautioned*
TV-PG	*Parental Guidance Suggested*
TV-G	*General Audience*
TV-Y7	*Directed to Children 7 years and older*
TV-Y	*All Children*

Tip

To reset the ratings to View and V, press the RESET button on the remote.

4. Press the right arrow button to move the yellow highlight to the *Status* field.
5. Press the up or down arrow button to toggle between *View* and *Block*. The status for the rating listed to the left and all higher ratings automatically changes to *Block* (and *B*).
6. Press OK on the remote to return to the menu or exit the screen when you are finished.
7. Select *Lock Parental Controls* from the *Parental Controls* menu. Enter a password, and if you have not already set your password, you will be prompted to enter it again to confirm.



Viewing Age-Based Ratings

After you block age-based ratings, you have the option of changing some of the ratings back to *View*.

1. Determine which blocked rating you want to view.
2. Use the up and down arrow buttons to select the rating with a status of *Block*.
3. Press the right arrow button to move the yellow highlight to the rating status field.
4. Press the up button to select *View*.

Note: *The content status fields corresponding to the unblocked rating become View as well. They and the age-based rating status are the only fields that automatically change back to View when you complete this process.*

Note: *You must remember to lock Parental Controls for rating limits to take effect.*

Content Themes	
D	*Sexually explicit dialogue*
L	*Adult language*
S	*Sexual situations*
V	*Violence*
FV	*Fantasy Violence*
TV-Y	*All Children*

Blocking Specific Content Themes

You can block programs based on their content. (Content is represented by the D, L, S, V, FV and TV-Y on your screen. See the beginning of this section for details.) When you block a content theme for a particular rating, you automatically block that content theme for higher rated programs as well.

For example, if you do not want your child to watch programs that have adult language (L) rated TV-PG or higher, then you could block out all programming TV-PG and above containing adult language.

(Steps explained on next page)

Downloaded from www.Manualslib.com manuals search engine



To block program content:

1. Determine the lowest level of content you don't want the child to watch.
2. Use the up and down arrow buttons on the remote to scroll through the age-based ratings until the rating that corresponds with the lowest content you do not want the child to watch appears. (In the example above, you would scroll through the ratings until the TV-PG rating appeared.)
3. Press the right arrow button to move the highlight to the field corresponding with the content theme you want to block out.
4. Press the up or down arrow button to change content status from *V* to *B*. All higher ratings' content theme will automatically change to *B*.
5. Press OK to return to the menu or exit the screen.

Note: *Broadcasters are not required to provide content themes or age-based ratings. Programs received with no content themes will only be blocked if you block their age-based rating.*

Note: *You must remember to lock Parental Controls for rating limits to take effect.*



Viewing Specific Content Themes

If you block specific content themes, you have the option of going back and changing some of the content themes back to *(V) View*:

1. Determine the content themes you want to change to *(V) View*.
2. Use the up and down arrow buttons to scroll through the age-based ratings until the rating whose content theme you want to change to *View* appears.
3. Press the right arrow button to move the yellow highlight to a particular content theme status, such as the *B* under language (L) corresponding with TV-14.
4. Press the up or down arrow button to change its status back to *V*. Your child would then be able to watch programs with TV-14 adult language content, but not programs with TV-PG or TV-MA language content.

Note: *Only the content theme status corresponding to TV-14 (L) language changes to (V) View. Higher rated content themes, such as that for TV-MA language, do not change.*



V-Chip Movie Rating Limit

You set movie rating limits by blocking movies rated above a specified level. How to block movie ratings and view movie ratings is explained in the next two sections.

To access the *V-CHIP MOVIE RATING LIMIT* menu:

1. Press MENU on the remote control (the *TV MAIN MENU* appears).
2. Select *Parental Controls* (press 6).
3. Select *V-Chip Movie Rating Limit* (press 2).

Downloaded from www.Manualslib.com manuals search engine



Blocking Movie Ratings

If you only want your child to watch movies that have a PG rating and lower (in other words, movies rated PG and G), then you could automatically block out all other movies with higher ratings.

To block movies:

1. Highlight the *Rating* field and press the up and down arrow buttons to find the rating that is the lowest rating you don't want the child to watch. (In the example above, you would highlight the rating status button corresponding to PG-13, since the highest rating you want the child to watch is PG.)
2. Press the right arrow button to highlight the rating *Status* field. Press the up and down arrow buttons to change the button from *View* to *Block*. All higher ratings automatically change to *Block*.
3. Press OK to return to the menu or exit the screen.
4. If Parental Controls are not locked, you must lock them so the movie rating limits will take effect.

Note: *Some movies may be given a Not Rated (NR) rating. After blocking movie ratings, you must set NR to View separately to view NR movies.*



Viewing Movie Ratings

After you block movie ratings, you have the option of changing some of the rating status buttons back to *View*:

1. Highlight the *Rating* field and press the up and down arrow buttons to find the rating you want to view.
2. Press the right arrow button to highlight the rating *Status* field. Press the up and down arrows to change the button from *Block* to *View*.

For example, if movies with a rating of PG-13 and higher are blocked, you can change the rating status corresponding with NC-17. Your child would then be able to watch all movies with a G, PG, and NC-17 Rating.

3. Press OK to exit the screen, and be sure parental controls are locked.



V-Chip Unrated Program Block

Selecting this option lets you decide if programs that the V-Chip recognizes as "unrated" can be viewed. Note that "unrated" TV programs may include news, sports, political, religious, local and weather programs, emergency bulletins, public announcements, and programs without ratings.

View All unrated programs are available.
Block All unrated programs are not available.

Note: *You must remember to lock Parental Controls for rating limits to take effect.*

Downloaded from www.Manualslib.com manuals search engine


PARENTAL CONTROLS
1 V-Chip TV Rating Limit
2 V-Chip Movie Rating Limit
3 V-Chip Unrated Program Block
4 Channel Block
CHANNEL BLOCK
Channel # Status
59 HEADLN Block
Press ^ or v, keypad, or CH ^/v
to set channel, MENU to exit.

Channel Block

Selecting this option lets you decide what channels can be viewed.

View Makes the selected channel viewable.

Block The front panel and remote control CH (channel) buttons will tune only to channels that you have marked as *View*. The remote will still tune to the blocked channel if you use the digits to access the channel, but the channel will be blocked.

Don't forget to lock parental controls after you change the status of *Channel Block*. If you do not, the channel block will not take effect.

> ***Note:*** *If you have a digital cable box channels 126-999 can be blocked but will not be removable from your scan list.*



Front Panel Block

Selecting this option lets you block (disable) or unblock (enable) the TV's front panel. The remote still tunes to any channel. *Front Panel Block* can:

- Keep children from watching TV when the parent is not present.
- Keep young children from playing with the buttons.

(When using this as a Parental Control method, you should remove access to any remote that is capable of operating the television while you have the front panel blocked.)

Don't forget to lock parental controls after you change the status. If you do not, the front panel block will not take effect.



Lock/Unlock Parental Controls

Selecting this option lets you lock and unlock parental controls settings using a password.

If you do not lock parental controls, none of the settings for V-Chip, Channel Block, or Front Panel Block will take effect.

If you forget your password, simultaneously press and hold MENU on the television and volume down on the remote for 3 seconds. Nothing appears on the screen, Parental Controls simply unlock and you can re-enter a password via *Lock Parental Controls*.

Downloaded from www.Manualslib.com manuals search engine

Using the TV's Menu System

Chapter Overview:

- How to Use the Different Types of Menus
- Audio Menu
- Picture Quality Menu
- Screen Menu
- Channel Menu
- Time Menu

Downloaded from www.Manualslib.com manuals search engine

How to Use Your TV's Menu System

You use the buttons on the remote or the front of your TV to access the menu system and make changes to the settings.

The following pages explain how to use the different types of menus to adjust the features of your TV.



Tip

Feel free to explore the menu system. If you're ever unsure where you are in the menu system, or you're just plain tired of exploring, press CLEAR to remove the menus from the screen and start over again.

Menus

The first menu is called the Main menu. Press MENU on the remote or on the front panel to bring up the Main menu. Note that holding MENU for 2 seconds displays the GUIDE Plus+ system.

Menus take you to another menu or a control panel. There are two ways to select a choice in a menu:

- Use your arrow buttons on your remote control to highlight your choice, and press OK.
- Press a number button on the remote. For example, in the Main menu press 3 to go straight to the *Screen* menu.

Exiting a menu

There are three ways to exit a menu:

- Highlight *Exit* and press OK.
- Press 0 on the remote.
- Press CLEAR. The on-screen displays are cleared from the screen and you return to TV viewing.

Downloaded from www.Manualslib.com manuals search engine



Audio Menu

Mute Press OK to reduce the TV's volume to its minimum level. Press OK again to restore the volume.

Tone Controls Displays the slider controls for adjusting the TV's treble, bass and balance.

Audio Processor Displays a choice list of available audio modes, which control the way the sound comes through your speakers. You can also access the *AUDIO PROCESSOR* menu by pressing the SOUND button on the remote.

> ***Mono*** Plays the sound in mono only. Use this setting when receiving broadcasts with weak stereo signals.
>
> ***Stereo*** Splits the incoming stereo audio signal into left and right channels. Most TV programs and recorded materials have stereo audio. The word *STEREO* appears on the TV when you tune to a program that is broadcast in stereo.
>
> ***Expanded Stereo*** Electronically "widens" sound from stereo broadcasts, stereo VCRs, digital satellite systems, DVD players, and LaserDisc players for a fuller, more spacious sound.
>
> ***Sound Logic™ Stereo*** Reduces the annoying blasts in volume during commercial breaks, and also amplifies softer sounds in program material. Eliminates the need to constantly adjust volume control.
>
> ***Second Audio Program (SAP)*** Plays the program's audio in a second language, if one is available. The word *SAP* appears on the TV when you tune to a program that is broadcast with SAP information. SAP audio is broadcast in mono. SAP is also used to broadcast a program's audio with descriptions of the video for the visually impaired.

Audio Output & Speakers Displays a choice list that lets you turn the TV's internal speakers on or off, and set the audio outputs to fixed-level or variable control level.

> ***Variable Output, Speakers On*** This setting turns the TV's speakers on and allows variable output from the TV's audio output jacks.
>
> ***Variable Output, Speakers Off*** This setting turns the TV's speakers off and allows variable output from the TV's audio output jacks.
>
> ***Fixed Output, Speakers Off*** This setting turns the TV's speakers off and allows fixed output from the TV's audio output jacks to an external component such as a surround sound amplifier. With *Fixed Output On*, the TV's volume control, tone controls, and mute are disabled.

Downloaded from www.Manualslib.com manuals search engine



Picture Quality Menu

Basic Picture Controls Displays the five slider controls for adjusting the way the picture looks.

Contrast Adjusts the difference between the light and dark areas of the picture.

Color Adjusts the richness of the color.

Tint Adjusts the balance between the red and green levels.

Black Level Adjusts the brightness of the picture.

Sharpness Adjusts the crispness of the edges in the picture.

When exiting this menu, the *Save Personal Picture Preset* choice list will appear. You can choose either *Yes* or *No*. If you save the settings as a Personal Picture Preset, the TV will store the settings so you can re-select them quickly if someone changes the settings.

Tip

To quickly access the Picture Presets menu, press the RESET button on your remote control.

Picture Presets Displays a choice list that lets you select one of three preset picture settings: *Bright Lighting*, *Normal Lighting*, *Soft Lighting or Personal Picture Preset*. Choose the setting that is best for your viewing environment.

Auto Color Displays a choice list that lets you turn on the feature that automatically corrects the color of the picture. (This is especially useful for tracking realistic flesh tone colors as you switch from channel to channel.) Choose *On* or *Off*, depending on your preference.

Color Warmth Displays a choice list that lets you set one of three automatic color adjustments: *Cool* for a more blue palette of picture colors; *Normal*; and *Warm* for a more red palette of picture colors. The warm setting corresponds to the NTSC standard of 6500 K.



Screen Menu

Closed-Caption Display Displays a choice list that lets you choose the way closed captioning information is shown on the screen.

Off always No captioning information is displayed.

On always Captioning information is shown always, when available.

On when sound is muted Captioning information is shown, when available, whenever the TV's sound is muted. (To mute the sound, press the MUTE button.) The captioning information is not displayed when the sound is not muted.

Closed-Caption Mode Displays a choice list that lets you choose which captioning mode is used for displaying captioning information.

PIP Closed-Caption Display Displays a choice list that lets you choose the way PIP closed-caption is shown on the screen.

Off always No PIP closed-captioning information is displayed.

On always PIP closed-captioning information is always displayed.

Downloaded from www.Manualslib.com manuals search engine

Alternate with PIP button Captioning information is shown, when available, when you press the PIP button on the remote with the PIP window on the screen.

PIP Closed-Caption Mode Displays a choice list that lets you choose which PIP closed-captioning mode you want to use to display PIP closed-captioning information.

Menu Language Displays a choice list that lets you select your preferred language for the menus: *English*, *Spanish* or *French*.

Picture Tilt (Direct View TV 31" or above) Your TV has an extra large picture tube that makes it vulnerable to the effects of the Earth's magnetic field. You may need to adjust the picture tilt.

Using Closed Captioning

Many programs are encoded with closed-captioning information, which lets you display the audio portion of a program as text on the TV screen.

Closed captioning is not available on all channels at all times. Only specific programs encoded with closed-captioning information are applicable. When a program is closed captioned, the *CC* icon is displayed in the channel banner. See Chapter 3 for more information about the channel banner.



Tip

If you don't know which Closed-Caption mode to use, select CC1. CC1 is probably the mode that is used in your area. CC2, CC3, and CC4 are reserved for foreign languages, but are rarely used at this time.

Closed-Caption Modes

The TV offers eight closed-captioned modes, including four text modes.

To set the *Closed-Caption Mode*:

1. Select *Screen* from the Main menu.
2. Highlight *Closed-Caption Mode* and press OK (the *Closed-Caption Mode* appears).
3. Highlight your choice and press OK (the *Screen* menu appears again).

   Note: *The Text modes cover nearly half of the picture on the screen to display the closed-captioned text. Most broadcasters use the CC mode, which displays a few lines of captions at a time.*

Turning off Closed-Caption

1. Select *Screen* from the Main menu.
2. Press OK to select *Closed-Caption Display*.
3. Highlight *Off Always* and press OK. The closed captioning is turned off and you go back to the *Screen* menu.

Downloaded from www.Manualslib.com manuals search engine



Channel Menu

Signal Type Displays a choice list that lets you select the current antenna type. This option does not appear when the GUIDE Plus+ system is set up.

> ***UHF/VHF Antenna*** Choose this if you are currently using an off-air antenna for TV signals.
>
> ***Cable TV*** Choose this if you are currently using cable or a cable box for TV signals.

Auto Channel Search Tells the TV to search automatically for all the channels available through the antenna input. When the TV finds an active channel, it places it in the Normal channel list; inactive channels (weak stations or channels with no signal at all) will be removed from the channel list. If you are using a cable box and have set up the GUIDE Plus+ system, this option does not appear.

List and Labels Displays a control panel that lets you edit your Normal channel list and choose a six-character label for each channel. Follow the on-screen directions to enter your channels and other information.

> ***Channel #*** Use the up and down arrows to scroll up and down through the channels available via your antenna. You can enter the channel number directly using the number buttons.
>
> ***Normal List*** Only the channels included in the Normal list are available when you scan up and down using channel up and down. Use the up and down arrow buttons to indicate whether the channel number indicated is included (*Yes*) or is not included (*No*) in the Normal channel list.
>
> ***Channel Label*** Use the up and down arrow buttons to enter a six-character label for each channel. Hold the button down to scroll quickly through the characters. The TV can store up to 27 labels in memory.

Auto Tuning Displays a choice list that lets you set up the TV to automatically tune to the correct input channel when you press a component button (VCR1, DVD, VCR2, or SAT•CABLE) on the remote. Go to Chapter 3 for details about the Auto Tuning feature.

Tip

To enter a number greater than 99, press and hold "1" to enter the hundreds digit, then press the two remaining numbers.



Time Menu

Sleep Timer Displays a control panel that lets you select the amount of time you want to give the TV before it shuts itself off.

Schedule Displays a control panel that lets you set up a schedule for turning the TV on and off automatically. Reminder: you must turn the schedule On. The on-screen directions guide you through the steps needed to set the schedule.

Set Time Displays a control panel that lets you enter the current time. The on-screen directions guide you through the steps needed to set the time. If your GUIDE Plus+ system is set up, it will automatically update your time and this option will not appear.

Downloaded from www.Manualslib.com manuals search engine

Other Information

Chapter Overview:

- Troubleshooting
- Care and Cleaning
- Front Panel Buttons
- Limited Warranty
- Accessory Order Form
- Index

Changing Entertainment. Again.

Downloaded from www.Manualslib.com manuals search engine

Troubleshooting

Most problems you encounter with your TV you can correct by consulting the Troubleshooting list that follows.

TV Problems

TV won't turn on

- Press the TV button.
- Make sure the TV is plugged in.
- Check the wall receptacle (or extension cord) to make sure it is "live" by plugging in something else.
- Something might be wrong with your remote control. Press the POWER button on the front of the TV. If the TV turns on, check the remote control solutions on p. 56.
- The front panel controls may be locked (disabled). Use the remote control to unlock the front panel controls by selecting the *Front Panel Block* in the *Parental Controls* menu and choosing *View*.

Controls don't work

- If you're using the remote control, press the TV button first to make sure the remote is in TV mode.
- The front panel controls may be locked (disabled). Use the remote control to unlock the front panel controls by selecting the *Front Panel Block* in the *Parental Controls* menu and choosing *View*.
- Unplug the TV for two minutes and then plug it back in. Turn the TV on and try again.

TV turns off while playing

- Scheduled Off function may have been activated. Go to p. 52 for instructions.
- Electronic protection circuit may have been activated because of a power surge. Wait 30 seconds and then turn the TV on again. If this happens frequently, the voltage in your house may be abnormally high or low.

TV turns on unexpectedly

- Scheduled On or Watch from the GUIDE Plus+ system may have been activated. Go to p. 52 for instructions.

Blank screen

- Make sure the component connected to the TV is turned on.
- Try another channel.
- Press RESET, in case the picture controls are set too low.

When I turn on the TV an icon is moving on the screen

- Make sure you have removed the Demo Pin from the G-LINK jack on the back of your TV.

No sound, picture okay

- Maybe sound is muted. Press the volume up button to restore sound.
- Maybe speakers are turned off. Check the *Audio Output* and *Speakers* control panel in the *Audio* menu. Go to p. 49 for detailed instructions.
- If using S-VIDEO cables to connect a component, remember to also connect the component's left and right Audio Output Jacks to the TV's left and right INPUT Jacks.

Can't select certain channel

- Channel may be blocked or not approved in the *Parental Controls* menu.
- If using a VCR, make sure the TV/VCR button on the VCR is in the correct mode (press the TV/VCR button on your VCR).

Noisy stereo reception

- The station might be weak. Press the SOUND button on your remote control to change from stereo to mono.

Downloaded from www.Manualslib.com manuals search engine

Troubleshooting

No picture, no sound but TV is on

- Maybe the cable/air setting is set to the wrong position. Select *GUIDE Plus+ Menu* from the Main menu, select the *Setup* option, and provide the correct information on the following screens. Go to pages 16-17 for detailed instructions.
- The channel might be empty — change channels.
- If you're watching your VCR and it's connected with coaxial cable to the CABLE/ANTENNA jack, tune the TV to channel 3 or 4 (whichever channel is selected on the 3/4 switch on the back of your VCR). Also check to make sure the TV/VCR button on the VCR is in the correct mode (press the TV/VCR button on your VCR).

Sound okay, picture poor

- Check antenna connections. Make sure all of the cables are firmly connected to the jacks.
- Try adjusting sharpness function to improve weak signals. Go to page 50 for more instructions.

Black box appears on the screen

- Closed-captioning might be on. Check the *Closed-Caption Display* control panel in the *Screen* menu. Go to page 50 for more instructions.

Every time I turn on the TV, the Guide is on the screen

- The GUIDE Plus+ system automatically appears on the screen when you use the TV button on the remote to turn on the TV. You can turn off this feature by pressing GUIDE on your remote control and then select the Menu bar. Press the right arrow button to select *Setup*. Choose *Review options* and select *OFF*.

GUIDE Plus+ System Problems

GUIDE Plus+ setup won't switch to channel 9 for VCR and/or channel 02 cable box

- Make sure you have removed the Demo Pin from the G-LINK jack. Check to see if the G-LINK wands are positioned correctly in front of components' remote sensors.
- GUIDE Plus+ system control of cable box is slower than direct control of the box itself. Keep this in mind when changing channels.
- You may have an incorrect GUIDE Plus+ Channel Lineup. The guide may get out of sync with the cable provider. Use the *GUIDE Plus+ Setup* in the *GUIDE Plus+ Menu* to change the zip code to 99999. Turn the TV off for 10 minutes. Use Setup again to change the zip code back to the correct value. If asked, be sure to select the correct channel lineup from the on-screen list.

Program information doesn't download

- Review your setup information and make sure it's correct. Press MENU on the remote and select *GUIDE Plus+ Setup*. Go to page 16 for detailed instructions about the GUIDE Plus+ Setup menus.
- The TV must be off to download information. Leave your TV off overnight, for at least 10 hours, to receive the initial download for your area.
- If you're using a cable box, leave it on so you can receive program information.

Scheduled Watch or Record doesn't occur

- Check Schedule for timer conflicts. Go to page 52 for instructions.
- Make sure the wands of the G-LINK cable are placed in front of the remote sensor(s) on the component(s).
- Make sure your VCR is turned off during the time you've scheduled to record a program because the system turns the VCR on when it starts recording (if it's already on when recording starts, the system will turn it off).
- Make sure there is a tape in the VCR and that the VCR is connected properly.
- Be sure that you set up the VCR in the *GUIDE Plus+ Setup* menus. If you don't complete the *Configuring for a VCR* steps successfully, the Record option won't be available. Go to p. 18 for detailed instructions.
- If a cable box is attached to your TV, make sure you set it up correctly in the *GUIDE Plus+ Setup* menus. Go to page 16-17 for detailed instructions.

Downloaded from www.Manualslib.com manuals search engine

The Remote Control Doesn't Work

- Something might be between the remote and the remote sensor on the component. Make sure there is a clear path.
- Maybe the remote isn't aimed directly at the component (TV or VCR) that you're trying to operate.
- Maybe remote is not in TV Mode. Press the TV button so remote will control TV.
- Maybe batteries in remote are weak, dead or installed incorrectly. Put new batteries in the remote. (Note, if you remove the batteries, you may have to reprogram the remote to operate other components.)
- You might need to drain the remote's microprocessor: remove batteries and press the number 1 button for at least 60 seconds. Release the 1 button, replace the batteries, and (if necessary) program the remote again.

PIP (Picture-In-Picture Feature) Doesn't Work

- The PIP feature on this TV only works if you connect a second video source (like a VCR or satellite receiver), to your TV with audio/video cables. If you use a cable box, you may need extra equipment. Contact your cable company and/or go to page 12 for more details about a cable box connection.
- Make sure the remote is in the right mode. For example, once you turn on the VCR with the VCR1 button, you can't SWAP the pictures until you put the remote in TV mode. Just press the TV button.
- No signal or bad reception? Most VCRs and satellite receivers have an antenna or TV button. If your cable or off-air antenna goes into your VCR or satellite receiver, then into your TV, try pressing the antenna or TV/VCR button on the front of the component.

  Tip: If programmed to control your VCR, the ANTENNA button on the remote acts as a TV/VCR button.

Problems with V-Chip/Parental Controls

The rating limits don't work

- You must lock the settings. Go to the *TV MAIN MENU* (press MENU on your remote), select *Parental Controls* (press 6 on your remote), select *Lock Parental Controls* (press 6 on your remote).

I don't remember my password and I want to unlock the TV

- If you forget your password, simultaneously press and hold MENU on the television and volume down on the remote for 3 seconds. Nothing appears on the screen, Parental Controls simply unlock and you can re-enter a password via *Lock Parental Controls*.

The V-Chip won't let me watch a program even though it's not rated as violent.

- Maybe the movie was given an NR (Not Rated) status. After you block movie ratings, you must set *NR* to *View* separately in order to view movies with an NR rating.

Downloaded from www.Manualslib.com manuals search engine

Care and Cleaning

CAUTION: Turn OFF your TV before cleaning.
You can clean the TV as required, using a soft lint-free cloth. Be sure to occasionally dust the ventilation slots in the cabinet to help assure adequate ventilation.
The TV's screen may be cleaned with a soft, lint-free cloth as well. Take care not to scratch or mar the screen. If necessary, you may use a cloth dampened with warm water.
Never use strong cleaning agents, such as ammonia-based cleaners, or abrasive powder. These types of cleaners will damage the TV.

While cleaning do not spray liquid directly on the screen, or allow liquid to run down the screen and inside the TV. Also, avoid placing drinks or vases with water on top of the TV. This could increase the risk of fire or shock hazard or damage to the TV.

Caution: If fixed (non-moving) images are left on the screen for long periods, they may be permanently imprinted on the picture tube. Such images include network logos, phone numbers, and video games. This damage is not covered by your warranty. Extended viewing of channels displaying these images should be avoided.

Front Panel

If you can't find your remote control you can use the buttons on your TV to operate many of the TV's features.

MENU Brings up the TV MAIN MENU. When in the menu system, it selects highlighted items. Also returns you to the previous menu. Press and hold MENU for two seconds to access the GUIDE Plus+ system.

CH – Scans down through the current channel list. When you're using the TV's menu system, it acts like the arrow down button on the remote control.

CH + Scans up through the channel list. When you're using the TV's menu system, it acts like the arrow up button on the remote control.

VOL – Decreases the volume. When you're using the TV's menu system, it acts like the left arrow button on the remote control.

VOL + Increases the volume. When you're using the TV's menu system, it acts like the right arrow button on the remote control.

POWER Turns the TV on and off.

Downloaded from www.Manualslib.com manuals search engine

RCA TV Limited Warranty

What your warranty covers:

- Any defect in materials or workmanship.

For how long after your purchase:

- 90 days for labor charges.
- One year for parts.
- Two years for the picture tubes.

The warranty period for rental units begins with the first rental or 45 days from date of shipment to the rental firm, whichever comes first.

What we will do:

- Pay any Authorized RCA Television Service Center the labor charges to repair your television.
- Pay any Authorized RCA Television Service Center for the new or, at our option, refurbished replacement parts and picture tubes required to repair your television.

How you get service:

- For screen sizes of 26" and smaller: Take your RCA television to any Authorized RCA Television Service Center and pick up when repairs are complete.
- For screen sizes larger than 26": Request home or pick up, repair, and return service from any Authorized RCA Television Service Center, provided that your television is located within the geographic territory covered by an Authorized RCA Television Service Center. If not, you must take your television to the Service Center location at your own expense, or pay for the cost the Service Center may charge to transport your television to and from your home.
- To identify your nearest Authorized RCA Television Service Center, ask your dealer, look in the Yellow Pages, or call 1-800-336-1900.
- Show the Authorized Service Center Representative your sales receipt or other evidence of purchase date or first rental.

What your warranty does not cover:

- Customer instruction. (Your Owner's Manual clearly describes how to install, adjust, and operate your television. Any additional information should be obtained from your dealer).
- Installation and related adjustments.
- Signal reception problems not caused by your television.
- Damage from misuse or neglect.
- Batteries.
- Customer replacement fuses.
- Images burned onto the screen.
- A television that has been modified or incorporated into other products or is used for institutional or other commercial purposes.
- A television purchased or serviced outside the U.S.A.
- Acts of God, such as but not limited to lightning damage.

Product registration:

- Please complete and mail the Product Registration Card packed with your TV. It will make it easier to contact you should it ever be necessary. The return of the card is not required for warranty coverage.

How state law relates to this warranty:

- This warranty gives you specific legal rights, and you also may have other rights that vary from state to state.

If you purchased your television outside the United States:

- This warranty does not apply. Contact your dealer for warranty information.

Service calls which do not involve defective materials or workmanship are not covered by this warranty. Costs of such service calls are the sole responsibility of the purchaser.

Downloaded from www.Manualslib.com manuals search engine



VH81 (3-ft)

VH82 (6-ft)

Screw-on Cable *attaches to the round antenna connectors (called 75-ohm F-type) on the back of your VCR or TV. The ends screw onto the connectors for a secure connection.*



VH89 (6-ft)

Push-on Cable *attaches to the round antenna connectors (called 75-ohm F-type) on the back of your VCR or TV. Ends push on for a quick connection.*



Gold-Tipped cable

VH83 (6-ft)

Monaural VCR Dubbing Cable *Double cable that lets you connect the video and audio jacks of two VHS VCRs to duplicate tapes. Can also be used to connect a VCR to your TV. Cable is color-coded and shielded. Has RCA-type phono plugs on each end.*



Gold-Tipped cable

VH84 (6-ft)

Stereo VCR Dubbing Cable *Triple cable that lets you connect the* VIDEO *and* AUDIO *jacks of stereo components.*



VH976 (6-ft)

VH913 (12-ft)

S-Video Cable *has multi-pin connectors on each end for connecting S-Video components to your TV.*

Continued on next page.....

Detach Here

Accessory Order Form

Description	Part No.	Price	Qty	
Screw-on antenna cable (3-ft)	VH81	$3.95		
Screw-on antenna cable (6-ft)	VH82	$5.95		
Push-on antenna cable (6-ft)	VH89	$5.95		
Monaural VCR Dubbing Cable (6-ft)	VH83	$5.95		
Stereo VCR Dubbing Cable (6-ft)	VH84	$9.95		
S-Video Cable (6-ft)	VH976	$7.95		
S-Video Cable (12-ft)	VH913	$14.95		
2-way Signal Splitter	VH47	$3.95		
Amplified Antenna	ANT200	$49.95		
Antenna Mixer (not shown)	193984	$11.15		
Remote Control (CRK76TA1)	240895	$29.20		
Audio•Video Adapter (not shown)	228449	$4.45		

Prices are subject to change without notice.

Total Merchandise ..... $ _____

Sales Tax ..... $ _____

We are required by law to collect the appropriate sales tax for each individual state, country, and locality to which the merchandise is being sent.

Shipping and Handling ..... $ 5.00

Total Amount Enclosed ..... $ _____

Use VISA, MasterCard, or Discover Card preferably.

Money order or check must be in U.S. currency only.

No COD or CASH.

All accessories are subject to availability.

Where applicable, we will ship a superseding model.

Please complete other side also

Downloaded from www.Manualslib.com manuals search engine

Other Information

Charge your order on your VISA, MasterCard, or Discover Card by filling in below

USE YOUR CREDIT CARD

IMPORTANT: Copy complete account number from your VISA card

VISA

☐☐☐☐ ☐☐☐☐ ☐☐☐☐ ☐☐☐☐

My card expires: ☐☐ ☐☐

IMPORTANT: Copy complete account number from your MasterCard

MasterCard

☐☐☐☐ ☐☐☐☐ ☐☐☐☐ ☐☐☐☐

Copy Number above your name on MasterCard ☐☐☐☐ My card expires: ☐☐ ☐☐

IMPORTANT: Copy complete account number from your Discover Card

DISCOVER

☐☐☐☐ ☐☐☐☐ ☐☐☐☐ ☐☐☐☐

My card expires: ☐☐ ☐☐

AUTHORIZED SIGNATURE
(Credit card order will not be processed without signature)

Print or type your name and address clearly.

A complete and correct order will save you days of waiting.

Name: _____

Street: _____

_____ Apt: _____

City: _____

State: _____ Zip: _____

Daytime phone number: _____

Please make sure that both sides of this form have been filled out completely.

- Allow 4 weeks for delivery.
- All accessories are subject to availability.
- Prices are subject to change.

Detach Here



2-way Signal Splitter

Helps you connect a second TV or VCR.

Splitter VH47



Amplified Antenna

Allows you to quickly switch from the antenna signal to the cable or satellite signal without disconnecting the antenna.

ANT200



Remote Control

This is the remote control that came packed with your TV. Replacements or spares can be ordered as needed.

CRK76TA1

To Order

To place your order by phone, have your Visa, MasterCard or Discover Card ready and call the toll-free number listed below.

Use this number only to place an order for accessory items listed on this order form.

1-800-338-0376

To place your order by mail, detach and mail the completed order form with credit card information, money order or check in US currency (made payable to Thomson Consumer Electronics, Inc.) to the following address:

Video Accessories
PO Box 8419
Ronks, PA 17573

Downloaded from www.Manualslib.com manuals search engine

A

Accessories 59
Advanced connections 11, 12
Age-Based Ratings 40
ANTENNA button 22
Arrow buttons 22
Audio
  Menu 50
  Output Volume & Speakers 49
  Processor 49
Audio/Video cable 7
Auto
  Channel Search 15, 52
  Color 50
  Tuning 52
    DVD Channel 39
    SAT/CABLE Channel 39
    VCR Channels 39
AUX (auxiliary) button 22

B

Basic
  connections 8, 9
  Picture Controls 50
Batteries for the remote 14
Black Level 50
Block
  Age-Based Ratings 42
  Front Panel 46
  Movie Ratings 45
  Specific Content Themes 43
  V-Chip Unrated Program 45
Buttons, remote control 22

C

Cable Box
  code list 26
  connecting 12
Cables
  Audio/Video 7
  coaxial 7
  G-LINK 7
  S-Video 7
CC (Closed Captioning) 51
CH + button 22
CH - button 22
CH CTRL (channel control) button 22
Channel
  Banner 35, 36
  Block 46
  Labels 52
  Lineup 28
  Menu 52
  Search 15
Channels menu 34
CLEAR button 22
Closed Caption
  Display 50
  Mode 51
Coaxial cable 7
Code list
  Cable Box 26
  Satellite Receiver 26
  VCR 26
Color Warmth 50
Connections
  TV + VCR 8
  TV + VCR + Cable Box 12
  TV + VCR + Satellite Receiver 11
  TV Only 9
Content Themes 40
Contrast 50

D

Demo Pin 6, 8, 9, 11, 12
DVD
  button 22
  Channel 39

F

Finding the sensor 13
Fixed
  Images 57
  Output, Speakers Off 49
FORWARD button 22
Front panel 57
  block 46

G

G-LINK
  cable 7
  connecting 13
GO BACK button 22
Grid Guide menu 29
GUIDE button 22
GUIDE Plus+ system
  Channel Lineup 28
  Channels 35
  Downloading Information 28
  Setup 15

I

INFO button 22
Interactive setup 15

L

L.E.D. button 22
Labels 52
Language 51
Languages
  Selecting 15
Locating remote sensor 13
Lock, Parental Controls 46

M

Memory 52
Menu
  Audio 49
  Channel 52
  Channels 34
  Grid Guide 29
  Language 51
  Messages 33
  News 32
  Picture Quality 50
  Schedule 32
  Screen 50
  Setup 34
  Sort 31
  Time 52
MENU button 22
Menus
  GUIDE Plus+ System setup 15
Messages menu 33
Mono 49
Mute 49
MUTE button 22

N

News menu 32
Normal List 52
Number buttons 22

O

OK button 22
ON•OFF button 23

P

Parental Controls
  Locking, Unlocking 46
  menu 40
PAUSE button 23
Picture
  Presets 50
  Quality Menu 50
  Tilt 51
PIP (Picture-In-Picture)
  button 23
  buttons 37
  Troubleshooting 38
  Using 36
PLAY button 23

R

Rating Limits
  movies 44
  TV 41
REC•VCR+ button 23
Remote, batteries 14
Remote sensor 13
RESET button 23
REVERSE button 23

S

S-VIDEO
  cable 7
SAP 49
SAT•CABLE button 23
SAT/Cable Channel 39
Satellite Receiver
  code list 26
  connecting 11
Schedule
  menu 32
  time 52
Screen Menu 50
Second Audio Program (SAP) 49
Set
  DVD Channel 39
  SAT/CABLE Channel 39
  Time 52
  VCR1 Channel 39
  VCR2 Channel 39
Setup
  GUIDE Plus+ system menus 15
  menu 34
Sharpness 50
Signal Type
  Cable TV 52
  UHF/VHF Antenna 52
SKIP button 23
Sleep Timer 36, 52
Sort menu 31
SOUND button 23
Stereo 49
STOP button 23
SWAP button 23

T

Time
  Current 36
  Menu 52
Tint 50
Tone Controls 49
Troubleshooting 54
TV
  button 23
  connecting 9

U

UHF/VHF Antenna 52
Unlock, Parental Controls 46

V

V-Chip 40
  Age-Based Ratings 40
  Blocking Movies 44
  Content Themes 40
Variable Output, Speakers On, Off 49
VCR
  1 Channel 39
  2 Channel 39
  code list 26
  connecting 8
VCR1 button 23
VCR2 button 23
VOL+ button 23
VOL- button 23

W

Warranty 58
WHO•INPUT button 23

Downloaded from www.Manualslib.com manuals search engine

Please do not send any products to the Indianapolis address listed in this manual or on the carton. This will only add delays in service for your product.

THOMSON CONSUMER ELECTRONICS
10330 North Meridian Street
Indianapolis, IN 46290

©2000 Thomson Consumer Electronics, Inc.
Trademark(s)® Registered
Marca(s) Registrada(s)
Printed in USA
TOCOM 15489490

The following materials were used in printing this publication:

60%
RECYCLED PAPER
MINIMUM 20% POST CONSUMER

PRINTED WITH SOY INK™

Downloaded from www.Manualslib.com manuals search engine